


5-Unit Reel Mower

Owner's Operating Manual



Serial No. LM3210 : 10052-

"Required reading"

Read this manual and the Owner's Manual for the engine before using the machine.



Regulations

California Proposition65

(For California, USA)

WARNING:

Operating, servicing and maintaining a passenger vehicle or off-road vehicle can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, avoid breathing exhaust, do not idle the engine except as necessary, service your vehicle in a well-ventilated area and wear gloves or wash your hands frequently when servicing your vehicle. For more information go to www.P65Warnings.ca.gov/passenge r-vehicle.

318yi8-005

California Proposition65_001

CALIFORNIA SPARK ARRESTER

(For California, USA)



Operation of this equipment may create sparks that can start fires around dry vegetation.

A spark arrester may be required. The operator should contact local fire agencies for laws or regulations relating to fire prevention requirements.


The DPF installed on the engine of this machine meets requirements of California Public Resource Code Section 4443.

Thank you for purchasing the Baroness machine. This manual explains proper handling, adjustment, and inspection of your machine. Prior to use, carefully read this manual to thoroughly understand the contents for safe and correct operation.

We hope you will use the machine safely, and take advantage of its best performance.

Keeping the Owner's Operating Manual

Keep this Manual in the box located in the rear of the seat.



Keeping the Owner's Operating Manual_001

	I
1	IRov
	DOX

Introduction

Read this manual carefully to ensure that you thoroughly understand how to properly operate and maintain this machine, and to avoid causing injury to yourself or others.

The operator is responsible for operating the machine properly and safely.

Do not perform maintenance on the machine other than that described in this manual.

Be sure to also read the Owner's Manual for the engine, battery, etc.

Maintenance should only be performed by a certified specialist.

If you have any questions concerning maintenance or genuine parts, please contact your local Baroness dealer or Kyoeisha.

When making inquiries about this machine, please specify the machine's model designation and serial number.

When loaning or transferring this machine, please also provide this manual together with the machine.

Kyoeisha Co., Ltd.



The information described in this manual is subject to change for improvement without prior notice. When replacing parts, be sure to use genuine Baroness parts or parts designated by Kyoeisha. Note that the Baroness product warranty may not apply to defects caused by the use of parts from other companies.

Warning Symbols

This manual uses the following warning symbols for handling precautions that are important for your safety.



Warning symbol

696cq5-001

This symbol indicates the articles regarding "Danger," "Warning," or "Caution."

Those articles describe important safety precautions and so read them carefully to understand completely before operating the machine.

Failure to adequately follow these safety precautions may cause an accident.



This symbol indicates that serious injury or death will occur if the warning is ignored.



This symbol indicates that serious injury or death may occur if the warning is ignored.



This symbol indicates that injury or damage to property may occur if the warning is ignored.

Important

This symbol indicates precautions on the mechanism of the machine.

Purpose

This machine is intended for cutting turf grass at golf courses.

Do not use this machine in any way other than its intended purpose, and do not modify the machine.

Operating this machine for other purposes and modifying it may be very dangerous and may cause damage to the machine.

In addition, this machine is not authorized for operation as a special motor vehicle. Do not operate it on public roads.

LM3210

Introduction

Contents

Safety	Page 1-1
Safe Operating Practices	Page 1-2
Disposal	Page 2-1
Recycle and Waste Disposal	Page 2-2
Product Overview	Page 3-1
Specifications Names of Each Section Safety Signs and Instruction Signs	Page 3-4
Handling Instructions	Page 4-1
Inspection Before Use	Page 4-15 Page 4-19 Page 4-23 Page 4-25 Page 4-36 Page 4-64 Page 4-65
Maintenance	Page 5-1
Maintenance Precautions Maintenance Schedule DPF	Page 5-3
Jacking up the machine Greasing Maintenance (Mower)	Page 5-16
Maintenance (Main Body)	

LM3210

Contents

Safety

	,

S	Safe Operating Practices	Page	1-2
	Training	.Page	1-2
	Preparation	Page	1-2
	Operation	Page	1-3
	Maintenance and storage	Page	1-4

Safety

Failure to adequately follow these safety precautions may cause an accident resulting in injury or death.

▲ Danger

This machine is designed to ensure safe operation and has been tested and inspected thoroughly before shipment from the factory. The machine is equipped with safety devices to prevent accidents.

However, whether the machine demonstrates its original performance level depends on the manner in which it is operated and handled, as well as the manner in which it is managed on a daily basis.

Inappropriate use or management of the machine may result in injury or death. Observe the following safety instructions to ensure safe operation.

Safe Operating Practices

Training

- Read this manual and other training material carefully. Be familiar with the controls, safety signs, and the proper use of the equipment.
- 2. If the operator or mechanic can not read English it is the owner's responsibility to explain this manual to them.
- All operators and mechanics should seek and obtain professional and practical instruction.

The owner is responsible for training the users.

Such instruction should emphasize.

- [1] The need for care and concentration when working with ride-on machines.
- [2] Control of a ride-on machine sliding on a slope will not be regained by the application of the brake.

The main reasons for loss of control are

- Insufficient wheel grip
- Being driven too fast
- Inadequate braking
- The type of machine is unsuitable for its task
- Lack of awareness of the effect of ground conditions, especially slopes
- Incorrect hitching and load distribution

- 4. Never allow children or people unfamiliar with these instructions to use or service the machine.
 - Local regulations may restrict the age of the operator.
- The owner/user can prevent and is responsible for accidents or injuries occurring to themselves, other people, or property.
- Keep in mind that the owner, operator, and mechanic are responsible for accidents or hazards occurring to other people or their property.
- 7. The ROPS is an integral and effective safety device.
 - Do not remove or alter the ROPS.
- 8. Replace a damaged ROPS. Do not repair or alter.
- 9. You can find additional safety information where needed throughout this manual.
- 10. Determine the left and right sides of the machine from the normal operating position.

Preparation

- Evaluate the terrain to determine what accessories and attachments are needed to properly and safety perform the job. Only use accessories and attachments approved by the manufacturer.
- 2. While operating, always wear substantial footwear, long trousers, hard hat, safety glasses, and ear protection. Long hair, loose clothing, or jewelry may get tangled in moving parts. Do not operate the equipment when barefoot or wearing open sandals.
- 3. Inspect the area where the equipment is to be used and remove all objects such as rocks, toys and wire which can be thrown by the machine.
- 4. Keep children out of the operating area and under the watchful care of a responsible adult other than the operator.
- Exercise care in the handling of fuel.



Warning-Fuel is highly flammable. Take the following precautions.

[1] Store fuel in containers specifically designed for this purpose.

- [2] Add fuel before starting the engine. Never remove the cap of the fuel tank or add fuel while the engine is running or when the engine is hot.
- [3] Refuel outdoors only and do not smoke while refueling.
- [4] If fuel is spilled, do not attempt to start the engine but move the machine away from the area of spillage and avoid creating any source of ignition until petrol vapours have dissipated.
- [5] Replace all fuel tanks and container caps securely.
- 6. Check that operator's presence controls, safety switches and shields are attached and functioning properly. Do not operate unless they are functioning properly.
- 7. If the brake operation is faulty or the parking brake lever has noticeable play, be sure to adjust or repair them before operating the machine.
- 8. Replace faulty mufflers.
- 9. On multi-cylinder/multi-reel machines take care as rotating one cylinder/reel can cause other cylinder/reels to rotate.

Operation

- 1. Do not operate the engine in a confined space where dangerous carbon monoxide fumes can collect.
- 2. Only operate in good light, keeping away from holes and hidden hazards.
- Before attempting to start the engine, disengage all attachments, shift into neutral, and engage the parking brake.
 Only start engine from the operator's position.
 - Use seat belts if provided.
- 4. Remember there is no such thing as a safe slope. Travel on grass slopes requires particular care.
 - To guard against overturning:
 - [1] Do not stop or start suddenly when going up or downhill.
 - [2] Engage clutch slowly, always keep machine in gear, especially when traveling downhill.
 - [3] Machine speeds should be kept low on slopes and during tight turns.
 - [4] Stay alert for humps and hollows and other hidden hazards.

- [5] Never operate across the face of the slope, unless the machine is designed for this purpose.
- [6] Never drive the machine on a slope with an angle of gradient that is greater than that specified or in a place where there is a danger of the machine slipping.
- Use extra care while operating machine with a grass catcher or other attachments. They can affect the stability of the machine.
- Never operate the machine with damaged guards, shields, or without safety protective devices in place.
 Be sure all interlocks are attached, adjusted and functioning properly.
- 7. Do not change the engine governor settings or overspeed the engine. Operating the engine at excessive speed may increase the hazard of personal injury.
- 8. Do the following before leaving the operator's position.
 - [1] Stop on level ground.
 - [2] Disengage the power take-off and lower the attachments.
 - [3] Change into neutral and set the parking
 - [4] Stop the engine and remove the key.
- Disengage the drive to attachments, stop the engine, and remove the ignition key in the following conditions.
 - [1] Before refueling.
 - [2] Before making height adjustment unless adjustment can be made from the operator's position.
 - [3] Before cleaning blockages.
 - [4] Before checking, cleaning, or working the machine
 - [5] After striking a foreign object or if an abnormal vibration occurs. Inspect the machine for damage and make repairs before restarting and operating the equipment.
- 10. Keep hands and feet away from the cutting units and the rotating parts.
- 11. Do not mow in reverse unless absolutely necessary. Always look down and behind before and while backing.
- 12. Do not carry passengers.
- 13. Never operate while people, especially children, or pets are nearby.

Safety

- 14. Slow down and use caution when making turns and crossing roads and sidewalks.
- 15. Stop the blades rotating before crossing surfaces other than grass.
- 16. Disengage drive to attachments when transporting or not in use.
- 17. When using any attachments, never direct discharge of material toward bystanders nor allow anyone near the machine while in operation.
- 18. Do not operate the machine under the influence of alcohol or drugs.
- 19. Take care when loading or unloading the machine into a trailer or a truck. Load or unload the machine in a flat and safe place. Before loading or unloading, set the parking brake on the truck or trailer, stop the engine, and chock the wheels. When transporting the machine on a truck or a trailer, set the parking brake, stop the engine, and fasten the machine to the truck with a rope or other suitable restraining device that has sufficient strength. When using a loading ramp, select one with sufficient strength, length, and width and that will not cause the machine to slip.
- 20. Close the fuel valve before transporting the machine.
- Use care when approaching blind corners, shrubs, trees, or other objects that may obscure vision.
- 22. Do not take your eyes off the road ahead. Do not operate the machine with no hands.
- 23. Reduce the throttle setting during engine run-out and, if the engine is provided with a shut-off valve, turn the fuel off at the conclusion of operation.
- 24. Do not operate the machine when there is the risk of lightning.

Maintenance and storage

- Disengage drives on level ground, lower the attachments, set parking brake, stop engine and remove key from ignition. Wait for all movement to stop before adjusting, cleaning or repairing.
- When machine is to be parked, stored, or left unattended, lower the cutting units unless a positive machanical lock is provided.

- To reduce the fire hazard, keep the engine, silencer/muffler, battery compartment fuel storage area, cutting unit and drives free of grass, leaves, or excessive grease. Clean up oil or fuel spillage.
- 4. Allow the engine to cool before storing in any enclosure.
- 5. Only cover the machine with a sheet after hot parts have sufficiently cooled down.
- 6. Never store the equipment with fuel in the tank inside a building where fumes may reach an open flame or spark.
- If the engine is provided with a shut-off valve, shut off valve while storing or transporting.
- 8. Do not store fuel near flames.
- Never allow untrained personnel to service machine.
- 10. Allow the engine/muffler to cool before checking/maintenance.
- Appropriately manage and correctly use the tools necessary for servicing or adjusting the machine.
- 12. Use jack stands to support components when required.
- 13. Carefully release pressure from components with stored energy.
- 14. Be sure to depressurize the hydraulic system before performing maintenance operations on it such as removing hydraulic equipment.
- 15. Check whether line connectors in the hydraulic system are properly tightened. Before applying hydraulic pressure, check the connections of the hydraulic pressure lines and the condition of the hoses.
- 16. When checking the hydraulic circuit for pinhole leaks or oil leakage from nozzles, do not use your hands. Use items such as paper or corrugated cardboard to find leakage points. Be extremely careful with high-pressure oil as it may pierce your skin, resulting in an injury.

 If fluid is injected into the skin it must be surgically removed within a few hours by a doctor familiar with this form of injury or gangrene may result.
- 17. Disconnect battery before making any repairs. Disconnect the negative terminal first and the positive last. Reconnect positive first and negative last.

- 18. Make sure that parts such as wires are not touching each other and that their covers have not come off.
- 19. Use care when checking the cylinders/reels and bed knives.
 - [1] Wear gloves and use caution when servicing them.
 - [2] Be careful during adjustment of the machine to prevent entrapment of the fingers between moving blades and fixed parts of the machine.
- 20. On multi-cylinder/multi-reel machines take care as rotating one cylinder/reel can cause other cylinder/reels to rotate.
- 21. Keep hands and feet away from moving parts. If possible, do not make adjustments with the engine running.
- 22. Charge batteries in an open well ventilated area, away from spark and flames. Unplug charger before connecting or disconnecting from battery. Wear protective clothing and use insulated tools.
- 23. Keep all parts in good working condition and all hardware tightened. Replace all worn or damaged decals.
- 24. Keep all nuts, bolts and screws tight to be sure the equipment is in safe working condition.
- 25. If the fuel tank has to be drained, do this outdoors.
- 26. Swallowing engine coolant can cause injury or death; keep out of reach from children and pets.

Safety

Recycle and Waste Disposal	Page	2-2
About Recycle	.Page	2-2
About the Waste disposal	.Page	2-2

Disposal

Recycle and Waste Disposal

About Recycle

Recycling battery etc. is recommended for environmental conservation and economical use of resources.

It may be required by local laws.

About the Waste disposal

Make sure that waste generated when servicing or repairing the machine is disposed of in accordance with local regulations. (e.g. waste oil, antifreeze, rubber products, and wires etc.)

Specifications	Page 3-2
Specifications	Page 3-2
Names of Each Section	Page 3-4
Serial Number Plate	Page 3-5
Specification Decal	Page 3-5
Noise Emission Decal	Page 3-5
Year of Manufacture Decal	Page 3-5
Maintenance Decal	Page 3-5
ROPS Authentication Decal	Page 3-6
Battery capacity decal	Page 3-6
Recycle Decal	Page 3-6
Battery Danger Decal	Page 3-6
Safety Signs and Instruction Signs	Page 3-7
About Safety Signs and Instruction Signs	Page 3-7
Positions of Safety Decals and Instruction Decals	Page 3-7
Description of Safety Decals and Instruction Decals	Page 3-9

Product Overview

Specifications

Specifications

Model			LM3210 (Type_F)		LM3210 (Type_R)		
	Total length		124.06 in	315 cm	129.92 in	330 cm	
		During operation	144.49 in	367 cm	144.88 in	368 cm	
Dimension	Total width	During transport	92.52 in	235 cm	92.91 in	236 cm	
S		Roof	92.91 in	236 cm	93.31 in	237 cm	
	Total height	Steering handle	64.96 in	165 cm	65.35 in	166 cm	
Weight	Machine (empty fuel tank)	with ROPS, Roof	4265.87 lb	1,935 kg	4287.92 lb	1,945 kg	
	CR Brush (for o	ne machine)	48.50 lb	22.0 kg	-	-	
Minimum tu	ırning radius		125.98 in	320 cm	125.98 in	320 cm	
		Model	Kubota V2403-CR-TE	E4B	Kubota V2403-CR-TE	4B	
Engine		Туре	Vertical water-cooled with turbocharger	4-cycle diesel engine	Vertical water-cooled with turbocharger	4-cycle diesel engine	
		Total displacement	148.51 cu.in.	2,434 cm ³ (2.434 L)	148.51 cu.in.	2,434 cm ³ (2.434 L)	
		Maximum output	43.2 kW (58.7 PS)/2,	400 rpm	43.2 kW (58.9 PS)/2,	400 rpm	
			Diesel 13.47	Diesel 51.0 dm ³	Diesel 13.47	Diesel 51.0 dm ³	
Fuel tank c	apacity		U.S.gals	(51.0 L)	U.S.gals	(51.0 L)	
Fuel consumption		174 g/PS • h (rated output)	236 g/kW·h (rated output)	174 g/PS • h (rated output)	236 g/kW·h (rated output)		
Engine oil o	capacity		2.56 U.S.gals	9.7 dm ³ (9.7 L)	2.56 U.S.gals	9.7 dm ³ (9.7 L)	
	vidth (Mowing wi	dth)	125.98 in	320 cm	125.98 in	320 cm	
Operating height (Mowing height)		0.394 - 2.362 in	10 - 60 mm	0.669 - 2.677 in	17 - 68 mm		
Blades	3 1 2	- 3 - 4	7		5		
	Traveling		HST (2WD/4WD sele	ctable)	HST (2WD/4WD sele	ctable)	
Drive	Mowing		Hydraulic			Hydraulic	
Speed (HS	-	Forward	2WD: 0 - 9.63 mph 4WD: 0 - 6.22 mph	2WD: 0 - 15.5 km/h 4WD: 0 - 10.0 km/h	2WD: 0 - 9.63 mph 4WD: 0 - 6.22 mph	2WD: 0 - 15.5 km/h 4WD: 0 - 10.0 km/h	
		Reverse	0 - 3.73 mph	0 - 6.0 km/h	0 - 3.73 mph	0 - 6.0 km/h	
Speed (Me	chanical)		-		-	_	
Efficiency		8.22 acres/hour (2WD: 8.08 mph x mowing width x 0.8)	33,280 m ² /h (2WD: 13.0 km/h x mowing width x 0.8)	8.22 acres/hour (2WD: 8.08 mph x mowing width x 0.8)	33,280 m ² /h (2WD: 13.0 km/h x mowing width x 0.8)		
Maximum inclination for operation		15 degrees		15 degrees			
Front wheel		31 x 13.50 - 15		31 x 15.50 - 15			
Tire size		Rear wheel	20 x 12.00 - 10		20 x 12.00 - 10		
Tiro pnoum	atic pressure	Front wheel	20.30 psi	140 kPa (1.4 kgf/ cm ²)	20.30 psi	140 kPa (1.4 kgf/ cm ²)	
riie prieum	auc pressure	Rear wheel	20.30 psi	140 kPa (1.4 kgf/ cm ²)	20.30 psi	140 kPa (1.4 kgf/ cm ²)	
Battery		105D31R		105D31R			

^{*} The factory default maximum engine rpm is 2,600 rpm.

Page 3-2 Specifications

Sound pressure level

■Sound pressure level

This machine was confirmed to have a continuous A-weighted sound pressure level of 88 dB by measuring identical machines in accordance with the procedure specified in ISO5395-1:2013.

Sound power level

■Sound power level

This machine was confirmed to have a sound power level of 103 dB by measuring identical machines in accordance with the procedure specified in directive 2000/14/EC.

Vibration level

■Hand-arm vibration

This machine was confirmed not to exceed a vibration level of 2.5 m/s² to hands and arms by measuring identical machines in accordance with the procedure specified in ISO 5395-1:2013.


■Whole body vibration

This machine was confirmed not to exceed a vibration level of 0.5 m/s² to the whole body by measuring identical machines in accordance with the procedure specified in ISO 5395-1:2013.

Specifications Page 3-3

Product Overview

Names of Each Section




Names of Each Section_001

1	Mower unit up/down lever
2	Seat
3	Diff-lock switch
4	Tilt lever
5	Forward pedal
6	Reverse pedal
7	Lights
8	Mower unit #5
9	Mower unit #1
10	Mower unit #4
11	Mower unit #2
12	Fuel filler
13	Throttle knob
14	Hood
15	Radiator
16	Oil cooler
17	Radiator cover
18	Muffler
19	Mower unit #3
20	Oil gauge
21	Parking brake lever
22	Brake pedals
Α	Serial number plate
В	Specification decal
С	Decal, noise emission
D	Year of manufacture decal
Е	Maintenance decal
F	ROPS authentication decal
G	Battery capacity decal
Н	Recycle decal
I	Battery warning decal

Page 3-4 Names of Each Section

Serial Number Plate

The serial number plate indicates the model and serial number of the machine.




Serial Number Plate 001

Specification Decal

(For Europe)

The Specification decal indicates the CE marking, model , and weight, etc.




Specification Decal_001

Noise Emission Decal

(For Europe)

The noise emission decal indicates the sound power level determined by measuring identical machines in accordance with the procedure specified in the EC directives.




Noise Emission Decal_001

Year of Manufacture Decal

(For Europe)


The year of manufacture decal indicates the vear when this machine was manufactured.



Year of Manufacture Decal_001

Maintenance Decal

The maintenance decal indicates the necessary inspection and maintenance items for this machine.




Maintenance Decal 001

Names of Each Section Page 3-5

Product Overview

ROPS Authentication Decal

The ROPS authentication decal indicates the manufacturer, model, etc., in accordance with International Standard ISO 21299:2009.




ROPS Authentication Decal_001

Battery capacity decal

(For Europe)


The battery capacity decal indicates the capacity by 20HR and CCA.



Battery capacity decal_001

Recycle Decal

Recycle Decal illustrates Recycle Mark in accordance with local regulation.



Recycle Decal_001

(For USA)




Recycle Decal_002

Battery Danger Decal

(For USA)

Battery Danger Decal describes handling precautions for battery.



Battery Danger Decal_001

Page 3-6 Names of Each Section

Safety Signs and Instruction Signs

About Safety Signs and Instruction Signs


⚠ Warning

Safety decals and instruction decals are attached to this machine.


Make sure that they are preserved in their entirety. If they are damaged, become dirty, or peel off, replace them with new ones.

Part numbers for decals that need to be replaced are listed in the parts catalog. Order them from a Baroness dealer or Kyoeisha.


<u>Positions of Safety Decals and Instruction</u> Decals




Positions of Safety Decals and Instruction Decals_001



Positions of Safety Decals and Instruction Decals_002




Positions of Safety Decals and Instruction Decals_003




Positions of Safety Decals and Instruction Decals_004


Product Overview




Positions of Safety Decals and Instruction Decals_005



Positions of Safety Decals and Instruction Decals_006




Positions of Safety Decals and Instruction Decals_007



Positions of Safety Decals and Instruction Decals_008

<u>Description of Safety Decals and Instruction Decals</u>



LM3210-0901Z0

Decal, operation

1

⚠ Warning

Read the Owner's Operating Manual.

2

A Warning

Apply the parking brake, stop the engine, and then remove the ignition key before leaving the machine.

3.

♠ Danger

Flying objects - Be sure that people around the machine keep a safe distance away.

4.

♠ Danger

May cut your hand or leg - Keep hands and feet away from moving parts.

5.

qigqnx-084

▲ Danger

Rollover - Do not work on any slopes of 15 degrees or more.

When you descend a slope, fasten your seatbelt, lower the mower units, and then drive at low speed.

K4205001840


Sticker, reel start/stop

1.

▲ Warning

Read the Owner's Operating Manual.

- 2. Procedure to Start Engine Read the Owner's Operating Manual.
- [1] Sit on the seat.
- [2] Turn the key to the "ON (GLOW)" position, and then wait for the "BARONESS" logo to go off.
- [3] Turn the key to the "START" position.
- [4] Depress the brake pedal to release the parking brake.




2

1

Safety Signs and Instruction Signs

Product Overview



8	K4209001000 qigqnx-021	K4209001000 Decal, diesel fuel refueling hole Use diesel fuel.
9	K4205001940 qigqnx-041	K4205001940 Decal, caution fire A Danger Keep fire away.
10	qigqnx-067	K4205001900 Decal, caution arm lock
11	K4205001970 qigqnx-045	K4205001970 Decal, caution spouting coolant Caution Caution for spouting coolant - Do not open while hot.
12	qigqnx-038	K4205001930 Decal, caution to injure A Caution May pinch - There is a risk of being pinched.
13	qigqnx-039	K4205001950 Decal, caution exhaust gas Warning Caution for exhaust gas
14	ULTRA LOW SULFUR DIESEL FUEL ONLY K4209001530 qigqnx-083	K4209001530 Decal, indicating diesel fuel Use ultra-low sulfur diesel fuel (sulfur-free diesel fuel).

Product Overview

15	ROLL-OVER PROTECTIVE STRUCTURE To maintain operator protection and ROPS certification: Replace damaged ROPS, do not repair or revise Any alteration of ROPS must be approved by manufacturer K4205001710	K4205001710 Decal, caution to ROPS Replace damaged ROPS. Do not repair or modify. (Only when equipped with ROPS)
16	qigqnx-015	K4205002090 Decal, caution to noise

Inspection Before Use	Page 4-2	Instruction Decals	Page 4-25
Dool Cuttor (Cutting Culinder) and		Proximity Sensors	Page 4-29
Reel Cutter (Cutting Cylinder) and Bed Knife (Bottom Blade)	Page 4-2	Relays	Page 4-29
Radiator Cover	-	Reel Rotation Switch	
Radiator		2WD/4WD Selector Switch	Page 4-30
Coolant	_	DPF Auto Regeneration Inhibit	
Oil cooler	-	Switch	_
Hydraulic Oil	•	DPF Parked Regeneration Switch	Page 4-31
Air Cleaner		Light Switch	_
Battery	_	Reel Reverse Switch	_
Tire		Reel Rotation/Stop Switching Lever	_
Brake	•	Reel Rotation Adjustment Valve	•
Belt	•	Mower Lock Lever (Latch)	_
Around the Engine	_	Mower Unit Up/Down Lever	_
Engine Oil	•	Throttle Knob	_
Fuel	_	Diff-Lock Switch	_
Water Separator	_	Traveling Pedal	Page 4-34
Oil Leakage	-	Brake Pedal	_
on Louinago	r ago i i i	Parking Brake Lever	Page 4-35
Tightening torques	Page 4-15	Hood	Page 4-35
Standard tightening torques	Page 4-15	Underseat Cover	Page 4-36
	•	Instruments	Page 4-36
Principal tightening torques	Page 4-17	mstruments	i age 1 -50
Adjustment Before Operating		Description of Monitor	
Adjustment Before Operating	Page 4-19		Page 4-36
Adjustment Before Operating Adjustment of Steering Wheel	Page 4-19	Description of Monitor	Page 4-36 Page 4-36
Adjustment Before Operating Adjustment of Steering Wheel Adjustment of Seat	Page 4-19Page 4-19Page 4-19	Description of Monitor	Page 4-36 Page 4-36
Adjustment Before Operating Adjustment of Steering Wheel Adjustment of Seat Adjustment of Blade Engagement	Page 4-19 Page 4-19 Page 4-19 Page 4-20	Description of Monitor	Page 4-36 Page 4-36 Page 4-64
Adjustment Before Operating Adjustment of Steering Wheel Adjustment of Seat Adjustment of Blade Engagement Adjustment of Cutting Height	Page 4-19 Page 4-19 Page 4-19 Page 4-20	Description of Monitor	Page 4-36 Page 4-36 Page 4-64 Page 4-64
Adjustment Before Operating Adjustment of Steering Wheel Adjustment of Seat Adjustment of Blade Engagement	Page 4-19Page 4-19Page 4-19Page 4-20Page 4-20	Description of Monitor Main Menu Items Travel of Machine Moving the Machine	Page 4-36 Page 4-36 Page 4-64 Page 4-64 Page 4-64
Adjustment Before Operating Adjustment of Steering Wheel Adjustment of Seat Adjustment of Blade Engagement Adjustment of Cutting Height Adjustment of Cutter Adjustment	Page 4-19Page 4-19Page 4-19Page 4-20Page 4-20Page 4-20	Description of Monitor Main Menu Items Travel of Machine Moving the Machine Towing the Machine Cutting Work	Page 4-36 Page 4-64 Page 4-64 Page 4-64 Page 4-65
Adjustment Before Operating Adjustment of Steering Wheel Adjustment of Seat Adjustment of Blade Engagement Adjustment of Cutting Height Adjustment of Cutter Adjustment Spring	Page 4-19Page 4-19Page 4-19Page 4-20Page 4-20Page 4-22Page 4-22	Description of Monitor Main Menu Items Travel of Machine Moving the Machine Towing the Machine Cutting Work Cutting Work	Page 4-36Page 4-64Page 4-64Page 4-64Page 4-65Page 4-65
Adjustment Before Operating Adjustment of Steering Wheel Adjustment of Seat Adjustment of Blade Engagement Adjustment of Cutting Height Adjustment of Cutter Adjustment Spring Adjustment of Reel Cover	Page 4-19Page 4-19Page 4-19Page 4-20Page 4-20Page 4-22Page 4-22Page 4-22	Description of Monitor Main Menu Items Travel of Machine Moving the Machine Towing the Machine Cutting Work Cutting Work Transporting	Page 4-36Page 4-64Page 4-64Page 4-64Page 4-65Page 4-65Page 4-66
Adjustment Before Operating Adjustment of Steering Wheel Adjustment of Seat Adjustment of Blade Engagement Adjustment of Cutting Height Adjustment of Cutter Adjustment Spring Adjustment of Reel Cover Adjustment of CR Brush Procedure to Start / Stop Engine	Page 4-19Page 4-19Page 4-19Page 4-20Page 4-20Page 4-22Page 4-22Page 4-22Page 4-22Page 4-22	Description of Monitor Main Menu Items Travel of Machine Moving the Machine Towing the Machine Cutting Work Cutting Work	Page 4-36Page 4-64Page 4-64Page 4-64Page 4-65Page 4-65Page 4-66
Adjustment Before Operating Adjustment of Steering Wheel Adjustment of Seat Adjustment of Blade Engagement Adjustment of Cutting Height Adjustment of Cutter Adjustment Spring Adjustment of Reel Cover Adjustment of CR Brush Procedure to Start / Stop Engine Start / Stop of Engine	Page 4-19Page 4-19Page 4-19Page 4-20Page 4-20Page 4-22Page 4-22Page 4-22Page 4-23Page 4-23	Description of Monitor Main Menu Items Travel of Machine Moving the Machine Towing the Machine Cutting Work Cutting Work Transporting	Page 4-36Page 4-64Page 4-64Page 4-64Page 4-65Page 4-65Page 4-66
Adjustment Before Operating Adjustment of Steering Wheel Adjustment of Seat Adjustment of Blade Engagement Adjustment of Cutting Height Adjustment of Cutter Adjustment Spring Adjustment of Reel Cover Adjustment of CR Brush Procedure to Start / Stop Engine Start / Stop of Engine Safety Mechanisms	Page 4-19 Page 4-19 Page 4-19 Page 4-20 Page 4-20 Page 4-22 Page 4-22 Page 4-22 Page 4-23 Page 4-23 Page 4-23 Page 4-24	Description of Monitor Main Menu Items Travel of Machine Moving the Machine Towing the Machine Cutting Work Cutting Work Transporting	Page 4-36Page 4-64Page 4-64Page 4-64Page 4-65Page 4-65Page 4-66
Adjustment Before Operating Adjustment of Steering Wheel Adjustment of Seat	Page 4-19Page 4-19Page 4-19Page 4-20Page 4-20Page 4-22Page 4-22Page 4-23Page 4-23Page 4-24Page 4-24	Description of Monitor Main Menu Items Travel of Machine Moving the Machine Towing the Machine Cutting Work Cutting Work Transporting	Page 4-36Page 4-64Page 4-64Page 4-64Page 4-65Page 4-65Page 4-66
Adjustment Before Operating Adjustment of Steering Wheel	Page 4-19Page 4-19Page 4-19Page 4-20Page 4-20Page 4-22Page 4-22Page 4-23Page 4-23Page 4-24Page 4-24	Description of Monitor Main Menu Items Travel of Machine Moving the Machine Towing the Machine Cutting Work Cutting Work Transporting	Page 4-36Page 4-64Page 4-64Page 4-64Page 4-65Page 4-65Page 4-66
Adjustment Before Operating Adjustment of Steering Wheel	Page 4-19 Page 4-19 Page 4-19 Page 4-20 Page 4-20 Page 4-22 Page 4-22 Page 4-23 Page 4-23 Page 4-24 Page 4-24 Page 4-24	Description of Monitor Main Menu Items Travel of Machine Moving the Machine Towing the Machine Cutting Work Cutting Work Transporting	Page 4-36Page 4-64Page 4-64Page 4-64Page 4-65Page 4-65Page 4-66
Adjustment Before Operating Adjustment of Steering Wheel	Page 4-19 Page 4-19 Page 4-19 Page 4-20 Page 4-20 Page 4-22 Page 4-22 Page 4-23 Page 4-23 Page 4-24 Page 4-24 Page 4-24	Description of Monitor Main Menu Items Travel of Machine Moving the Machine Towing the Machine Cutting Work Cutting Work Transporting	Page 4-36Page 4-64Page 4-64Page 4-64Page 4-65Page 4-65Page 4-66

Inspection Before Use

Be sure to perform an inspection before you start using the machine so that you will be able to take advantage of its optimum performance for a long period of time.

Reel Cutter (Cutting Cylinder) and Bed Knife (Bottom Blade)

Inspection of Reel Cutter (Cutting Cylinder) and Bed Knife (Bottom Blade)

The reel cutter (cutting cylinder) and bed knife (bottom blade) may become dull due to frequent use, objects crushed during mowing, or damage caused during transportation. Inspect the reel cutter (cutting cylinder) and bed knife (bottom blade), and if necessary, adjust the blade engagement, perform back lapping, or resharpen or replace the reel cutter (cutting cylinder) and the bed knife (bottom blade).

- 1. Check to see whether or not the edge of the reel cutter (cutting cylinder) and the bed knife (bottom blade) are too blunt to cut.
- 2. Make sure that the reel cutter (cutting cylinder) and the bed knife (bottom blade) are not cracked.
- 3. Check to see how much the reel cutter (cutting cylinder) and the bed knife (bottom blade) are worn.
- Make sure that the reel cutter (cutting cylinder) and the bed knife (bottom blade) have not changed color due to heat from grinding.
- 5. Check to see whether or not the second edge face (relief) remains at the point of reel cutter (cutting cylinder).
- 6. Make sure that the welding between the reel cutter (cutting cylinder) and the disc has not come off.

Radiator Cover

Inspection of Radiator Cover

- 1. Make sure that there is no damage to the radiator cover.
- 2. Make sure that the radiator cover is not contaminated.

Cleaning of Radiator Cover


Important

An unclean radiator cover may cause overheating or damage to the engine. It may also cause malfunction of the hydraulic system.

If the radiator cover has been contaminated with dust, be sure to clean it.

After operating the machine in a dusty environment, it is important to remove dust from the cover as soon as possible.

1. Open the radiator cover.



Cleaning of Radiator Cover_001

1 Radiator cover

2. Carefully clean the front and back of the radiator cover with water or compressed air.

Page 4-2 Inspection Before Use

Radiator

Inspection of Radiator

For details on handling the engine, please refer to the Engine's Owner's Manual.

- 1. Make sure that there is no damage to the radiator.
- 2. Make sure that the radiator is not contaminated.

Cleaning of Radiator

For details on handling the engine, please refer to the Engine's Owner's Manual.

Important

An unclean radiator may cause overheating or damage to the engine.

It may also cause malfunction of the hydraulic system.

Important


Do not use solid objects, such as a spatula or screwdriver, or high-pressure water to clean the radiator or oil cooler.

Otherwise, special fins or tubes may be damaged, possibly resulting in reduced cooling performance or coolant leakage.

If the radiator has been contaminated with dust, be sure to clean it.

After operating the machine in a dusty environment, it is important to remove dust as soon as possible.

- 1. Open the radiator cover.
- 2. Unlock the rubber catches on the left and right of the oil cooler, and then tilt the oil cooler.



Cleaning of Radiator_001

1	Oil cooler
2	Rubber catch
3	Radiator

3. Carefully clean the front and back of the radiator with water or compressed air.

Coolant

Inspection of Coolant

For details on handling the engine, please refer to the Engine's Owner's Manual.




Do not touch the radiator or coolant during engine operation or right after the engine has been turned off.

Due to high temperatures, doing so could cause burns.



Inspection should take place after the engine has well cooled down.

1. Make sure that the coolant level in the reserve tank is between "Full" and "Low."



Inspection of Coolant_001

1 Reserve tank

Coolant Supply

For details on handling the engine, please refer to the Engine's Owner's Manual.



Do not touch the radiator or coolant during engine operation or right after the engine has been turned off.

Due to high temperatures, doing so could cause burns.

After the radiator has well cooled down, open the radiator cap.



Supply coolant after the engine has well cooled down.



The radiator cap is pressurized.

If you remove the radiator cap while the engine is overheated, hot steam will burst out, possibly resulting in burns.

Make sure that the water temperature and pressure are reduced, and then grab the cap with a thick cloth and gradually open the cap.

Important


When you supply coolant, be sure to use clean water, such as tap water.

During winter, remove coolant. Alternatively, mix long-life coolant and clean water, and then pour it into the radiator and reserve tank.

Relationship between concentration of longlife coolant (LLC) and freezing temperature

	-
Freezing temperature	LLC concentration (volume %)
Down to -10°C (14°F)	20 %
Down to -15°C (5°F)	30 %
Down to -20°C (-4°F)	35 %
Down to -25°C (-13°F)	40 %


 If the coolant level in the reserve tank is lower than the "LOW" mark, open the reserve tank cap and fill the tank with clean water up to the "FULL" mark.



Coolant Supply_001

Reserve tank

- If no coolant is in the reserve tank, follow the steps below to fill the tank with clean water.
 - [1] Open the radiator cap, and then supply clean water up to the opening.
 - [2] Open the reserve tank cap, and then supply clean water up to the "FULL" mark.



Coolant Supply_002

Radiator cap

Page 4-4 Inspection Before Use

Change of Coolant

For details on handling the engine, please refer to the Engine's Owner's Manual.



When you replace the coolant, be sure to drain it into a bowl and discard it in accordance with local laws and regulations.

▲ Warning

Do not touch the radiator or coolant during engine operation or right after the engine has been turned off.

Otherwise, you may get burned due to high temperatures.

After the radiator has well cooled down, open the radiator cap.

▲ Caution

Change coolant after the engine has well cooled down.

Important

When you change coolant, be sure to use clean water, such as tap water.

During winter, remove coolant. Alternatively, mix long-life coolant and clean water, and then pour it into the radiator and reserve tank.

For details on changing coolant, please refer to the separate Engine Operating Manual. Coolant quantity, including that of the reserve tank, is 12.0 dm³ (12.0 L).

Oil cooler

Inspection of Oil Cooler

- 1. Make sure that there is no damage to the oil cooler.
- 2. Make sure that the oil cooler is not contaminated.

Cleaning of Oil Cooler



An unclean oil cooler may cause malfunction of the hydraulic system.

Important


Do not use solid objects, such as a spatula or screwdriver, or high-pressure water to clean the radiator or oil cooler.

Otherwise, special fins or tubes may be damaged, possibly resulting in reduced cooling performance or coolant leakage.

If the oil cooler has been contaminated with dust, be sure to clean it.

After operating the machine in a dusty environment, it is important to remove dust as soon as possible.

- 1. Open the radiator cover.
- 2. Unlock the rubber catches on the left and right of the oil cooler, and then tilt the oil cooler.



Cleaning of Oil Cooler_001

1	Oil cooler
2	Rubber catch
3	Radiator

3. Carefully clean the front and back of the oil cooler with water or compressed air.


Inspection Before Use

Hydraulic Oil

Inspection of Hydraulic Oil

The oil gauge is on the side of the hydraulic tank.

- 1. Lower the mower units and maintain that position on a level surface.
- 2. Make sure that the oil level is at the middle of the oil gauge.



Inspection of Hydraulic Oil_001

1 Oil gauge

3. Check underneath the machine for oil leakage.

Hydraulic Oil Supply


Important

Do not mix different types of oil.

Important

Use Shell Tellus S2M46 (or equivalent) as hydraulic oil.

 If the oil level is low, remove the left tank cover, and then open the tank cap and supply oil.



Hydraulic Oil Supply_001

1	Tank cap
2	Oil gauge

- 2. Tighten the tank cap securely.
- 3. Start the engine, raise and lower the mower units, and turn the steering wheel left and right.

Move forward and reverse repeatedly several times.

- 4. Raise the mower units and maintain that position on a level surface, and then check to see if the oil level is at the middle of the oil gauge. If necessary, supply oil.
- 5. Check underneath the machine for oil leakage.
- 6. Attach the left tank cover.

Change of Hydraulic Oil



When you change the hydraulic oil, be sure to drain it into a bowl and discard it in accordance with local laws and regulations.



If the oil emulsifies or if it becomes even slightly less transparent, change the oil immediately.




Be careful with hot oil, which could cause burns if it contacts your skin.

Important

Use Shell Tellus S2M46 (or equivalent) as hydraulic oil.

- 1. Follow the steps below to remove the old oil.
 - [1] Start and run the engine to warm up the oil.
 - [2] On a level surface, lower the mower units, and then stop the engine.
 - [3] Remove the drain plug of the hydraulic tank, and then drain the old oil into a container.

[4] Wind new sealing tape on the drain plug, and then attach it to the hydraulic tank.




Change of Hydraulic Oil_001

1	Hydraulic tank
2	Drain plug

- 2. Remove the left tank cover.
- 3. Open the tank cap, and then pour new oil from the fill port until the oil level reaches the middle of the oil gauge on the hydraulic tank.

The hydraulic tank capacity is approximately 44.0 dm³ (44.0 L).



Change of Hydraulic Oil_002

1	Tank cap
2	Oil gauge

- 4. Tighten the tank cap securely.
- Start the engine, raise and lower the mower units, and turn the steering wheel left and right.
 - Move forward and reverse repeatedly several times.
- 6. Raise the mower units and maintain that position on a level surface, and then check to see if the oil level is at the middle of the oil gauge. If necessary, supply oil.
- 7. Check underneath the machine for oil leakage.
- 8. Attach the left tank cover.

Air Cleaner


Inspection of Air Cleaner

For details on handling the engine, please refer to the Engine's Owner's Manual. Liners and piston rings so that the engine will always operate smoothly.

A contaminated air cleaner element may cause malfunction of the engine.

1. Inspect the air cleaner by checking the vacuum indicator.

If the air cleaner element is contaminated, the vacuum indicator will display a red ring.



Inspection of Air Cleaner_001

1	Air cleaner
2	Vacuum indicator

- 2. Make sure that there is no damage to the air cleaner.
- 3. Make sure that the air cleaner is not contaminated.

Cleaning of Air Cleaner


For details on handling the engine, please refer to the Engine's Owner's Manual. A contaminated air cleaner element may cause malfunction of the engine.

To maximize the life of the engine, clean the air cleaner properly.

- 1. Follow the steps below to clean the outer element.
 - [1] Remove the clips from the three locations, remove the air cleaner cap, and then remove the outer element.
 - [2] While paying close attention not to damage the outer element, tap a solid portion of the outer element or blow compressed air from its inside to remove dust and dirt.

If the outer element is extremely contaminated, replace it with a new one.


- [3] Attach the outer element to the air cleaner body.
- [4] Replace the air cleaner cap, and then fix it securely using the clips.



Cleaning of Air Cleaner_001

1	Outer element
2	Inner element
3	Clip
4	Air cleaner cap
5	Air cleaner body
6	Vacuum indicator

2. Press the reset button for the vacuum indicator.



Cleaning of Air Cleaner 002

1	Reset button
2	Vacuum indicator

Important

The inner element cannot be cleaned.

3. Replace the inner element every year or when it becomes damaged or dirty.

Change of Air Cleaner

For details on handling the engine, please refer to the Engine's Owner's Manual. A contaminated air cleaner element may cause malfunction of the engine. To maximize the life of the engine, replace the

air cleaner element at the appropriate times.

- 1. The timing for replacing the air cleaner element is described below.
 - [1] Replace the air cleaner element in accordance with the Maintenance Schedule.
 - [2] If it is significantly contaminated, replace it, even if the hours of operation do not exceed the specified time.
- 2. Replace the air cleaner element in the same manner as cleaning the air cleaner. "Cleaning of Air Cleaner" (Page 4-7)

Battery

Inspection of Battery

For details on handling the battery, please refer to the Battery's Owner's Manual.



Keep away from fire while inspecting or charging the battery.

The battery may explode.

Warning


Do not allow the battery fluid level to become lower than the LOWER LEVEL (minimum fluid level line).

The battery may explode if it is used or charged while the battery fluid level is at the LOWER LEVEL (minimum fluid level line).



Perform operations after the muffler and engine have sufficiently cooled. Otherwise, you may suffer burns.

- 1. Clean the areas around the battery fluid level lines using a cloth damped with water.
- 2. Make sure that the battery fluid level is between the UPPER LEVEL (maximum fluid level line) and the LOWER LEVEL (minimum fluid level line).



Inspection of Battery_001

1	UPPER LEVEL
2	LOWER LEVEL

Supply of Battery Fluid

For details on handling the battery, please refer to the Battery's Owner's Manual.

♠ Danger

Be careful not to let your skin, eyes or clothes, etc., come into contact with the battery fluid or accidentally swallow the fluid.

Should your skin or clothes come into contact with the battery fluid, immediately wash them away with water.

▲ Warning


When you supply battery fluid, wear protective garments and safety glasses, etc.



Implement after the engine and muffler etc. have well cooled down.

Otherwise you may get burned.

 If the battery fluid level is lower than halfway between the UPPER LEVEL (maximum) line and LOWER LEVEL (minimum) line, add purified water up to the UPPER LEVEL (maximum) line.



Supply of Battery Fluid_001

1	UPPER LEVEL
2	LOWER LEVEL

Tire

Inspection of Tires

- 1. Check the pneumatic pressure of the tires.
- 2. Make sure that there are no cracks, damage or abnormal wear.

Type_F

Tire size	Pneumatic pressure
Front wheel (31 x 13.50 - 15)	140 kPa (1.4 kgf/cm ²)
Rear wheel (20 x 12.00 - 10)	140 kPa (1.4 kgf/cm ²)

Type_R

Tire size	Pneumatic pressure
Front wheel (31 x 15.50 - 15)	140 kPa (1.4 kgf/cm ²)
Rear wheel (20 x 12.00 - 10)	140 kPa (1.4 kgf/cm ²)

Brake

Inspection of Brake

While traveling, depress the brake pedal firmly to make sure that the brake is applied effectively.

Inspection of Parking Brake

- 1. Make sure that the parking brake is applied after depressing the brake pedal and pulling the parking brake lever.
- Make sure that the parking brake is not applied even slightly after depressing the brake pedal to release the parking brake lever.

Belt

Inspection of Belt



Caution

The engine must be stopped when the belt is inspected.



Caution

If you have removed the cover during inspection, make sure that you replace it in the original position securely.

If the cover remains removed, the operator may come in contact with the rotating objects or belt, possibly resulting in injuries.

Important

A slacking or damaged belt or damaged fan may cause overheating or lack of a battery charge.

- 1. Press the middle of the belt with your finger to check the belt tension.
- 2. Make sure that there are no cracks, damage or abnormal wear.

Around the Engine

Inspection of Engine-Associated Parts

For details on handling the engine, please refer to the Engine's Owner's Manual.

- 1. Check the fuel system parts for loosened or cracked joints and leakage. Replace the parts if necessary.
- 2. Blow compressed air to clean any grass or flammable materials that may be attached on or around the muffler.

Engine Oil


Inspection of Engine Oil

Important

Securely tighten the oil level gauge and oil filler cap.

1. Stop the engine, wait for 10 to 20 minutes for the engine to cool down, and then check the oil level.


2. Position the machine so that the engine will be level, and then insert the oil level gauge all the way to check the oil level.



Inspection of Engine Oil 001

1 Oil gauge	
-------------	--

3. The appropriate oil level should be between the upper and lower limit lines on the gauge.



Inspection of Engine Oil_002

1	Oil level gauge
2	Upper limit
3	Lower limit

Page 4-10 Inspection Before Use

Supply of Engine Oil

For details on handling the engine, please refer to the Engine's Owner's Manual.

Important

Do not supply too much engine oil. Otherwise, the engine may be damaged.

Important

Do not mix different types of engine oil.


Important

Be sure to use engine oil that is classified as JASO DH-2 or API Service Grade CJ-4, with SAE viscosity that is appropriate for the operating environment (ambient temperature).

Important

Securely tighten the oil level gauge and oil filler cap.

- If the engine oil level is lower than the lower limit line on the oil level gauge, supply engine oil through the oil filling port. Remove the oil filler cap, and then supply new engine oil until the oil reaches a level in between the upper and lower limit lines on the oil level gauge.
- 2. Replace the oil filler cap.



Supply of Engine Oil_001

Oil filler cap

 It will take a while for the supplied engine oil to descend into the oil pan.
 Check the oil level again 10 to 20 minutes Change of Engine Oil

For details on handling the engine, please refer to the Engine's Owner's Manual.

▲ Warning

When you change the engine oil, be sure to drain it into a bowl and discard it in accordance with local laws and regulations.

▲ Caution

Be careful with hot oil, which could cause burns if it contacts your skin.

Important


Be sure to use engine oil that is classified as JASO DH-2 or API Service Grade CJ-4, with SAE viscosity that is appropriate for the operating environment (ambient temperature).

Important

Securely screw in the oil level gauge and oil filler cap.

Change the engine oil more frequently if the engine oil is contaminated, or if you use the machine in dusty areas or operate the engine at high loads or in high temperatures.

- Move the machine onto a level surface, stop the engine, remove the drain plug while the engine oil is warm, and then drain the oil into a bowl.
- 2. Replace the drain plug in the engine.



Change of Engine Oil_001

Drain plug


Inspection Before Use

after supplying the oil.

 Through the oil filling port, supply new engine oil until the oil reaches a level in between the upper and lower limit lines on the oil level gauge.

Engine oil quantity is approximately 9.7 dm³ (9.7 L).

4. Replace the oil filler cap.



Change of Engine Oil_002


1 Oil filler cap

 It will take a while for the supplied engine oil to descend into the oil pan.
 Check the oil level again 10 to 20 minutes after supplying the oil.

Fuel

Inspection of Fuel Quantity

With the machine on a level surface, observe the fuel level in the monitor to check the fuel level.



Inspection of Fuel Quantity_001

1	Monitor
2	Fuel level

Fuel Supply

▲ Danger

Do not supply additional fuel after the fuel level indicates 100%.

If you supply too much fuel, it might overflow from the fuel cap when you travel or work on a slope.

▲ Warning

Keep fire away while refueling. Do not smoke while refueling.


▲ Caution

Use ultra-low sulfur diesel fuel (sulfur-free diesel fuel).

For details on fuel types, please refer to the Engine's Owner's Manual.

If the fuel level in the monitor indicates a level close to 0%, supply fuel (diesel) at your earliest convenience.

The fuel tank capacity is approximately 51.0 dm³ (51.0 L).




Fuel Supply_001

1	Monitor
2	Fuel level

Air Bleeding of Fuel System

A priming pump is installed on the feed pump. Repeat pushing the top of the priming pump with a finger until feeling resistance to bleed air from the fuel system.



Air Bleeding of Fuel System_001

1	Feed pump
2	Priming pump

Water Separator

Inspection of Water Separator


For details on handling the engine, please refer to the Engine's Owner's Manual.

Important

If water contaminates the fuel, the supply pump and injector may seize.

The water separator removes water from the fuel

 Make sure that debris and water have not accumulated in the cup.
 With the float raised, water incorporation is



Inspection of Water Separator_001

	· —
1	Float
2	Cup
3	Water drain plug
4	Element
5	Air-bleeding bolt

Draining of Water Separator


For details on handling the engine, please refer to the Engine's Owner's Manual.

Important

If water contaminates the fuel, the supply pump and injector may be burnt out.

Drain the water at least every 50 hours and whenever the float is raised by water.

- 1. Follow the steps below to drain the water.
 - [1] Stop the engine, and then turn the key switch to the "OFF" position.
 - [2] Place a container under the water separator.
 - [3] Loosen the water drain plug and airbleeding bolt to drain the water into the container.



Draining of Water Separator_001

1	Float
2	Cup
3	Water drain plug
4	Element
5	Air-bleeding bolt

- [4] Tighten the water drain plug and airbleeding bolt.
- [5] Bleed air from the fuel system.

Cleaning of Water Separator

For details on handling the engine, please refer to the Engine's Owner's Manual.


Important

If water contaminates the fuel, the supply pump and injector may be burnt out.

Clean the water separator at least every 500 hours and whenever debris has accumulated in the cup.

- 1. Follow the steps below to clean the water separator.
 - [1] Stop the engine, and then turn the key switch to the "OFF" position.
 - [2] Place a container under the water separator.
 - [3] Remove and clean the cup, element and float.

Replace the element with a new one when replacement needed.



Cleaning of Water Separator_001

	1	Float
	2	Cup
	3	Water drain plug
	4	Element
	5	Air-bleeding bolt

- [4] Install the cup, element and float in their original positions.
- [5] Bleed air from the fuel system.

Oil Leakage

Inspection of Oil Leakage



▲ Caution

When performing maintenance on the hydraulic system, lower the mower units.

After approximately 50 hours of operation, some tightened portions may be loosened and oil and grease may leak.

Be sure to retighten the parts.

Check the bottom of the machine for oil and grease leakage.

Page 4-14 Inspection Before Use

Tightening torques

Standard tightening torques

Bolts and Nuts

Important

A number of bolts are used in each part of this machine.

Be sure to re-tighten the bolts and nuts, because they may be loosened at the earlier stage of the use

As to the bolts and nuts without any special instruction, tighten them in appropriate tightening torque with proper tool.

Too much tightening may cause the looseness or damage of the screw.

The strength of tightening is determined by types of screws, strength, the friction of thread face or base face and others.

The table below is for the galvanized or parkerized bolts.

In case that the strength of internal thread is weak, it is not applied.

Do not use rusty or sand attached "screw."

Otherwise, it may cause insufficient tightening even if you apply the specified tightening torque.

The friction of the screw face becomes higher and the tightening torque is canceled out by the friction, therefore sufficient tightening cannot be applied.

If "screw" is wet by water or oil, do not tighten it with normal tightening torque.

If the screw is wet, the torque coefficient will get smaller and it may result in too much tightening.

Too much tightening may cause looseness by the screw stretched or result in damage.

Do not use a bolt experienced too much burden.

Using the impact wrench requires the skill.

Do exercise as much as possible for steady tightening.

	General bolt				
	Strength classification 4.8				
Nominal diameter	M 4 T (tib3yb-001				
	N-m	kgf-cm	lb-in		
M5	3 - 5	30.59 - 50.99	26.55 - 44.26		
M6	7 - 9	71.38 - 91.77	61.96 - 79.66		
M8	14 - 19	142.76 - 193.74	123.91 - 168.17		
M10	29 - 38	295.71 - 387.49	256.68 - 336.34		
M12	52 - 67	530.24 - 683.20	460.25 - 593.02		
M14	70 - 94	713.79 - 958.52	619.57 - 831.99		
M16	88 - 112	897.34 - 1142.06	778.89 - 991.31		
M18	116 - 144	1,182.85 - 1,468.37	1,026.72 - 1,274.54		
M20	147 - 183	1,498.96 - 1,866.05	1,301.10 - 1,619.73		
M22	295	3,008.12	2,611.05		
M24	370	3,772.89	3,274.87		
M27	550	5,608.35	4,868.05		
M30	740	7,545.78	6,549.74		

Tightening torques Page 4-15

			Heat-ti	reated bolt			
	Strength classification 8.8 8 T				Strength classification 10.9		
Nominal diameter				11 (11T) (10.9) tib3yb-003			
	N-m	kgf-cm	lb-in	N-m	kgf-cm	lb-in	
M5	5 - 7	50.99 - 71.38	44.26 - 61.96	7 - 10	71.38 - 101.97	61.96 - 88.51	
M6	8 - 11	81.58 - 112.17	70.81 - 97.36	14 - 18	142.76 - 183.55	123.91 - 159.32	
M8	23 - 29	234.53 - 295.71	203.57 - 256.68	28 - 38	285.52 - 387.49	247.83 - 336.34	
M10	45 - 57	458.87 - 581.23	398.30 - 504.51	58 - 76	591.43 - 774.97	513.36 - 672.68	
M12	67 - 85	683.20 - 866.75	593.02 - 752.34	104 - 134	1,060.49 - 1,366.40	920.50 - 1186.03	
M14	106 - 134	1,080.88 - 1,366.40	938.21 - 1,186.03	140 - 188	1,427.58 - 1,917.04	1,239.14 - 1,663.99	
M16	152 - 188	1,549.94 - 1,917.04	1,345.35 - 1,663.99	210 - 260	2,141.37 - 2,651.22	1,858.71 - 2,301.26	
M18	200 - 240	2,039.40 - 2,447.28	1,770.20 - 2,124.24	280 - 340	2,855.16 - 3,466.98	2,478.28 - 3,009.34	
M20	245 - 295	2,498.27 - 3,008.12	2,168.50 - 2,611.05	370 - 450	3,772.89 - 4,588.65	3,274.87 - 3,982.95	
M22	-	-	-	530	5,404.41	4,691.03	
M24	-	-	-	670	6,831.99	5,930.17	
M27	-	-	-	1,000	10,197.00	8,851.00	
M30	-	-	-	1,340	14,628.78	11,860.34	

Note:

The same values are applied to "fine screw thread."

Page 4-16 Tightening torques

Principal tightening torques

Tightening Torque by Model

LM3210

Tighten the following bolts and nuts at the torque specified in the table.

For thread locking adhesive, apply a middle strength thread locker (ThreeBond 1322 or equivalent anaerobic sealant).

	anaerobic sea	,		Т	ightening to	raue	Thread locking
	Location	Code	Part name	N-m	kgf-cm	lb-in	adhesive
	Motor housing	K0014160402	Bolt, heat-treated M16-40P1.5	152 - 188	1549.94 - 1917.04	1345.35 - 1663.99	_
	Motor	K0013140502	Bolt, heat-treated M14-50	100	1019.7	885.1	_
Front wheel	Wheel mounting base	1 1/4-18UNF	Slotted nut (Hydraulic motor)	400 - 430	4078.80 - 4384.71	3540.40 - 3805.93	_
Fro	Disc brake	K001A080401	Bolt, w/hexagon hole, M8-40	28 - 38	285.52 - 387.49	247.83 - 336.34	_
	Wheel	K0014120652	Bolt, heat-treated M12-65P1.5	67 - 85	683.20 - 833.75	593.02 - 752.34	_
Rear wheel	Wheel mounting base	K0138240002	24 slotted nut high P1.5	180 - 200	1835.46 - 2039.40	1593.18 - 1770.20	_
Real	Wheel	K0014120652	Bolt, heat-treated M12-65P1.5	67 - 85	683.20 - 866.75	593.02 - 752.34	_
Fror	nt axle	K0015200702	Bolt, heat-treated M20-70P1.5	370 - 450	3772.89 - 4588.65	3274.87 - 3982.95	_
Brake ass'y		K1720000190	Bolt, heat-treated M12P1.75	150 ± 15	1529.55 ± 152.96	1327.65 ± 132.77	0
		K0012120352	Bolt, heat-treated M12-35P1.25	67 - 134	683.20 - 1366.40	593.02 - 1186.03	_
-	ino	K0015120552	Bolt, heat-treated M12-55P1.25	67 - 134	683.20 - 1366.40	593.02 - 1186.03	_
Eng	ine	K0011100502	Bolt, heat-treated M10-50P1.25	45 - 76	458.87 - 774.97	398.30 - 672.68	_
		K0013121102	Bolt, heat-treated M12-110	67 - 134	683.20 - 1366.40	593.02 - 1186.03	_
Flywheel adapter		K0011100302	Bolt, heat-treated M10-30P1.25	45 - 76	458.87 - 774.97	398.30 - 672.68	_
		K0010100352	Bolt, heat-treated M10-35	45 - 76	458.87 - 774.97	398.30 - 672.68	_
loin	+	K001A100401	Bolt, w/hexagon hole, M10-40	80	815.76	708.08	_
Join	ι	K0013100352	Bolt, heat-treated M10-35	45 - 76	458.87 - 774.97	398.30 - 672.68	_
King	pin stopper	K0010120502	Bolt, heat-treated M12-50	52 - 67	530.24 - 683.20	460.25 - 593.02	_
Tie rod		K1610000020	Slotted nut of tie rod end RH	45	458.87	398.30	_

Page 4-17 Tightening torques

Location	Code	Part name	N-m	ightening to	rque lb-in	Thread locking adhesive
Tie rod	K1611000020	Slotted nut of tie rod end LH	45	458.87	398.30	_
Piston pump	K0013120502	Bolt, heat-treated M12-50	67 - 134	683.20 - 1366.40	593.02 - 1186.03	_
Tandem gear pump	K0069000251	Bolt, 3/8-16 UNC 31.8	29 - 38	295.71 - 387.49	256.68 - 336.34	_
Diff-lock valve	K001A100151	Bolt, w/hexagon hole, M10-15	29 - 38	295.71 - 387.49	256.68 - 336.34	_
Bumper	K0010120302	Bolt, heat-treated M12-30	67 - 134	683.20 - 1366.40	593.02 - 1186.03	_
Cover mounting bracket	K0000080202	Bolt, M8-20	9 - 14	91.77 - 142.76	61.96 - 123.91	_
Bed knife (bottom blade)	K0071001182	Screw, heat-treated flathead M10-16	29 - 38	295.71 - 387.49	256.68 - 336.34	_

Page 4-18 Tightening torques

Adjustment Before Operating

Adjustment of Steering Wheel



Since it is dangerous, do not adjust the steering wheel while traveling.

▲ Caution

Be sure the steering wheel position is securely locked.


It would be extremely dangerous if it becomes loose while traveling.

The steering wheel can be adjusted up or down.

Adjust the position according to the operator's body size.

Shift the tilt lever to the "FREE" position, move the steering wheel to the position that suits your work requirements, and then shift the tilt lever to the "LOCK" position to secure the steering wheel in place.

The tilt lever is located in the right front of the driver's position.



Adjustment of Steering Wheel 001

-		
	1	Steering wheel
	2	Tilt lever
	Α	FREE (released)
	В	LOCK (locked)


Adjustment of Seat

Use the seat adjustment levers to adjust the seat.

Adjust the position according to the operator's body size.

1. Use the forward/backward adjustment lever to adjust the seat back and forth.


- 2. Use the backrest tilt adjustment lever to adjust the angle of the backrest.
- 3. Turn the suspension adjustment handle to adjust the firmness of the seat suspension. Observe the suspension adjustment scale while making adjustments. (50 130 kg)
- 4. Turn the armrest adjustment knob to adjust the angle of the armrests.



Adjustment of Seat_001

1	Forward/backward adjustment lever
2	Backrest tilt adjustment lever
3	Suspension adjustment handle
4	Suspension adjustment scale
5	Armrest adjustment knob

5. Lift the seat to adjust its height to one of three positions.



Adjustment of Seat_002


Α	Three positions

Adjustment of Blade Engagement



When handling the reel cutter (cutting cylinder) and the bed knife (bottom blade), wear gloves to protect your hands. Pay attention not to let the reel cutter (cutting cylinder) catch your gloves. Otherwise, you may injure your hand or fingers.

- 1. Stop the engine.
- 2. Set the reel rotation/stop switching lever to the "Stop" position.




Adjustment of Blade Engagement_001

1	Reel rotation/stop switching lever
Α	Rotate
В	Stop

- 3. With the cutter adjustment nut, adjust the engagement between the reel cutter (cutting cylinder) and the bed knife (bottom blade) so that newspaper (two to three sheets) will be cut by the edge of both blades when the blades in their entirety come slightly into contact with each other.
- 4. Insert two or three strips of newspaper into the space between the reel cutter (cutting cylinder) and the bed knife (bottom blade) at an angle of 90 degrees. Then, rotate the reel cutter (cutting cylinder) counter-clockwise (when you face the mower unit from the left) to check the sharpness of the blades. Check the sharpness of the entire range (three or four points from left edge to right) of the reel cutter (cutting cylinder).

- If a gap is created between edges:
 Loosen the cutter adjustment nut to apply more contact pressure between the reel cutter (cutting cylinder) and the bed knife (bottom blade).
- If the reel cutter (cutting cylinder) is too tight to turn:
 Tighten the cutter adjustment nut to
 - Tighten the cutter adjustment nut to reduce the contact pressure between the reel cutter (cutting cylinder) and the bed knife (bottom blade).
- If the blades still cannot cut well:
 Perform back lapping of the reel cutter (cutting cylinder).



Adjustment of Blade Engagement_002


1	Cutter adjustment nut
2	Spring
3	Pipe with cutter adjusting screw

Adjustment of Cutting Height

Roller (Roller Type)

Adjust the cutting height to fit your cutting work


You can adjust the front roller in four stages.



Roller (Roller Type)_001

Attach the front roller in a position within the range of cutting height that suits your work requirements.

- 1. To increase cutting height:
 - [1] Loosen cutting height adjustment nut A, tighten cutting height adjustment nut B, then lower the rear roller.
 - [2] Use the cutting height gauge to determine the position, then tighten cutting height adjustment nut A securely.
- 2. To decrease cutting height:
 - [1] Loosen cutting height adjustment nut B, tighten cutting height adjustment nut A, then raise the rear roller.
 - [2] Use the cutting height gauge to determine the position, then tighten cutting height adjustment nut B securely.




Roller (Roller Type) 002

	(
1	Reel cutter (cutting cylinder)
2	Front roller
3	Cutting height gauge
4	Bed knife (Bottom blade)
5	Cutting height adjustment nut A
6	Cutting height adjustment nut B
7	Rear roller
Α	Cutting height

Front Wheel Type

Adjust the cutting height to fit your cutting work.


You can adjust the wheel to one of four levels.



Front Wheel Type_001

Attach the wheel in a position within the range of cutting height that suits your work requirements.

- 1. To increase cutting height:
 - [1] Loosen cutting height adjustment nut A, tighten cutting height adjustment nut B, then lower the rear roller.
 - [2] Use the cutting height gauge to determine the position, then tighten cutting height adjustment nut A securely.
- 2. To decrease cutting height:
 - [1] Loosen cutting height adjustment nut B, tighten cutting height adjustment nut A, then raise the rear roller.
 - [2] Use the cutting height gauge to determine the position, then tighten cutting height adjustment nut B securely.




Front Wheel Type_002

1	Reel cutter (cutting cylinder)
2	Front Wheel
3	Cutting height gauge
4	Bed knife (bottom blade)
5	Cutting height adjustment nut A
6	Cutting height adjustment nut B
7	Rear roller
Α	Cutting height

Adjustment of Cutter Adjustment Spring

If the diameter of the reel cutter (cutting cylinder) becomes smaller, adjust the cutter adjustment spring.

- 1. Adjust the blade engagement.
- 2. Loosen the pipe with cutter adjusting screw, and then adjust the length of the spring coil to approximately 40 mm (1.575 in.).



Adjustment of Cutter Adjustment Spring_001

1	Pipe with cutter adjusting screw
Α	40 mm (1.575 in.)


Adjustment of Reel Cover

Note:

Depending on the specifications, this function may not be available.

The angle of the reel cover can be adjusted.

1. Pull the right and left knobs securing the reel cover to release it.



Adjustment of Reel Cover_001

,	-
1	Reel cover
2	Knob
3	Cover adjustment plate
Α	Fully open
В	15 degrees closed
С	30 degrees closed
D	Fully closed

2. Select the hold position of the cover adjustment plate and secure the reel cover.

Adjustment of CR Brush

Note:

Depending on the specifications, this function may not be available.




Pressing the brush against the roller too tightly could cause the belt to slip or break.

Important

CR brush prevents clippings etc. from adherence to the rear roller owing to rotating brush.

1. Loosen the bolts and nuts attached to the both ends of CR brush.



Adjustment of CR Brush_001

1	Bolts
2	Nuts
3	Brush
4	Rear roller

Securely tighten the bolts and nuts loosened in step 1 as the gap between the brush and rear roller is adjusted to between 0 and 1 mm.

Procedure to Start / Stop Engine

Start / Stop of Engine

Procedure to Start Engine



When starting the engine, the reel cutter (cutting cylinder) may rotate slowly. Before starting the engine, make sure that there are no other people or obstacles around the machine.




When restarting the engine after it has been turned off, wait until the electromagnetic pump has fully stopped before restarting the engine. The electromagnetic pump will stop approximately 7 seconds after the key switch is turned to the "OFF" position.

Important

Starter operation must take 15 seconds or less.

If the engine does not start, stop using the battery for 30 to 60 seconds to avoid exhausting the battery.


- 1. Sit on the seat.
- 2. Make sure that the parking brake is applied.
- 3. Make sure that the knife rotation switch is in the "OFF" position.
- 4. Make sure that the traveling pedal is in the neutral position.
- 5. Move the throttle knob halfway from the "Low speed" position toward the "High speed" position.



Procedure to Start Engine_001

1	Throttle knob
Α	High speed
В	Low speed

Switch the ignition key to the "ON (GLOW)" position.



Procedure to Start Engine_002


1	Ignition key
Α	OFF
В	ON (GLOW)
С	Unused
D	START



When the ignition key is switched to the "ON" position, "Warming up" may appear in the monitor display.

Do not start the engine until the message disappears.

7. Make sure that the glow plug is generating heat, the "BARONESS" logo or "Warming up" message appears in the monitor display, and the yellow and red LEDs are lit.



Procedure to Start Engine_003

1	Monitor display
2	Yellow LED
3	Red LED



Quickly returning the ignition key from the "START" position to the "ON" position may result in damage to the machine.

- 8. After the "BARONESS" logo and the yellow and red LEDs go off and the parameters (items and values such as the rotation speed) appear, immediately set the ignition key to the "START" position.
- 9. When the starter starts rotating and the engine starts, slowly return the ignition key to the "ON" position.
- 10. Move the throttle knob to the "Low speed" position, and then warm up the engine for 1-2 minutes.
- 11. Gradually move the throttle knob toward the "High speed" position.

Procedure to Stop Engine

- 1. Set the traveling pedal to the neutral position.
- 2. Apply the parking brake.
- 3. Set the reel rotation switch to the "OFF" position.
- 4. Shift the throttle lever to the "Low speed" position, and then idle the machine for 1-2 minutes.
- Switch the ignition key to the "OFF" position.
- 6. Make sure that the engine has stopped.
- 7. Remove the ignition key.
- Leave the driver's seat.

Safety Mechanisms

This machine features a safety device for starting/stopping the engine.

- As for starting the engine, the safety device prevents the engine from starting unless it meets each of the following four conditions.
 - · An operator is sitting on the seat.
 - The parking brake is applied.
 - The reel rotation switch is set to the "OFF" position.
 - The traveling pedal is set to the neutral position.

- 2. In the event the operator leaves the seat with the parking brake applied and the engine running, the safety device will be activated and will stop the engine under any of the following conditions:
 - The traveling pedal is not set to the neutral position. (The operator has depressed the traveling pedal.)
 - The reel rotation switch is set to the "ON" position.

Warning Mechanisms



When the buzzer (intermittent tone) sounds, be sure to stop operation since the engine is overheated.

Do not stop the engine without idling. Allow the engine to cool down, first. Keep the engine idling for about 5 minutes before stopping. Remove dust that is jamming in the radiator, air cleaner, and etc.

This machine features warning mechanisms for overheating, the hydraulic oil and the engine.

- 1. If the engine water temperature exceeds 115 degrees Celsius, a buzzer will sound. (intermittent tone)
- If the oil level in the hydraulic tank declines from the specified level by approximately 2.0 dm³ (2.0 L), a buzzer will sound. (continuous tone)
- 3. With an engine malfunction, a monitor LED lights up and a fault code appears.

Operation of Each Section

Precautions for Operating the Machine




Under any circumstances drive the machine at such a speed that you can stop it immediately for emergencies.

Cautions for when You Leave the Machine




If the brakes are not sufficiently effective, use the wheel stoppers to secure the machine.

Instruction Decals




Instruction Decals_001

1	Key switch icons Reel rotation switch icons	
2		
3	2WD/4WD selector switch icons	
4	DPF auto regeneration inhibit switch	
4	icons	
5	DPF parked regeneration switch icons	
6	Light switch icons	
7	Mower unit up/down lever icons	
8	Engine speed icons	



Instruction Decals_002

9	Sticker, tilt steering
10	Sticker, Parking brake
11	Differential lock decal



Instruction Decals_003

2	Decal, lapping
	, - - - 5

1	Key switch icons It illustrates the positions of the key switch. 1. OFF 2. ON 3. Unused 4. START	1 STOP 2 3 6n6oux-073
2	Reel rotation switch icons This illustrates rotation/stopping of the reel cutter (cutting cylinder). 1. Rotate 2. Stop	1 • 2 6n6oux-042
3	2WD/4WD selector switch icons This illustrates 2WD/4WD selection. 1. 4WD 2. 2WD	1 1 2 6n6oux-055
4	DPF regeneration inhibit switch icons This indicates the positions of the DPF regeneration inhibit switch. 1. Regenerate 2. Regeneration inhibited	2
5	DPF parked regeneration switch icons This indicates the position of the DPF parked regeneration switch. 1. Engaged	1 (P) 6n6oux-078

	T	
6	Light switch icons It illustrates ON/OFF of the light. 1. ON 2. OFF	■
7	Mower unit up/down lever icons It illustrates Up/Down of the mower unit. 1. Down 2. Up	1 1 2 6n6oux-041
8	Engine speed icons These indicate positions for low and high engine speeds. 1. Low speed 2. High speed	6n6oux-075
9	K4203001350 Sticker, tilt steering This shows the steering tilt directions and how to lock and release the position.	FREE LOCK 6n6oux-065
10	K4203001340 Sticker, Parking brake This shows how to lock and release the parking brake. 1. Locked 2. Released	(P) f1


11	K4203001420 Decal, differential lock This indicates the positions for engaging or releasing the differential lock. 1. Engaged 2. Released	Differential lock 1 A 2 V 1 6n6oux-076
12	K4203001590 Decal, lapping This indicates the direction of reel rotation. 1. OFF (cutting rotation) 2. ON (backlapping rotation)	1 2 OFF ON LAPPING 6n6oux-082

Proximity Sensors

There are three proximity sensors on mower arm fulcrums #3, #4 and #5.

These sensors detect the raised or lowered positions of mower units #3, #4 and #5.

The information is related to controlling rotation and stop of the reel cutters (cutting cylinders).



Proximity sensor


Relays

The relay box is located inside the right tank cover.

These relays control operation of the diff-lock, rotation of the reel cutters (cutting cylinders), and 2WD/4WD selection.

The operating condition can be checked by the illumination of the LEDs.

- · LEDs ① and ② light up when the diff-lock valve is in the "ON" position.
- LEDs ③ and ⑤ light up when the reel rotation switch is in the "ON" position and the mower units are lowered.
- LEDs ④ and ⑥ light up when the reel reverse switch is in the "ON" position and the mower units are lowered.
- · LED ⑦ is not used.
- LED ® lights up when the 2WD/4WD selector switch is in the "4WD" position, and then the machine enters 4WD.



Relays_001

1 Relay box

Reel Rotation Switch



Before you start cutting work, set the reel rotation switch to the "ON" position. At all other times, make sure it is set to the "OFF" position.


The reel rotation switch is located in the operation panel and operates rotation of the reel cutters (cutting cylinders) of the mower units.

When the reel rotation switch is set to the "ON" position, the reel cutters (cutting cylinders) in all mower units rotates.

When the reel rotation switch is set to the "OFF" position, the reel cutters (cutting cylinders) stop.

Note:

When the mower units are raised, the reel cutters (cutting cylinders) do not rotate, even if the switch is set to the "ON" position.



Reel Rotation Switch_001

1	Reel rotation switch
Α	ON
В	OFF


2WD/4WD Selector Switch



When working on a slope, be sure to use the machine in 4WD.

The 2WD/4WD selector switch is located in the operation panel.

When the switch is set to the "2WD" position, the machine will be in two-wheel drive (front-wheel drive). When it is set to the "4WD" position, the machine will be in four-wheel drive.



2WD/4WD Selector Switch 001

1	2WD/4WD selector switch
Α	4WD
В	2WD

DPF Auto Regeneration Inhibit Switch




Normally, set the DPF auto regeneration inhibit switch to the "Auto regeneration" position.

However, when operating in a location where fires may occur, set the DPF auto regeneration inhibit switch to the "Auto regeneration inhibit" position.

The DPF auto regeneration inhibit switch is located in the operation panel.


When the switch is set to the "Auto regeneration" position, auto regeneration is performed. When the switch is set to the "Auto regeneration inhibit" position, auto regeneration is inhibited.



DPF Auto Regeneration Inhibit Switch 001

1	DPF auto regeneration inhibit switch
Α	Auto regeneration
В	Auto regeneration inhibit

When the switch is set to the "Auto regeneration inhibit" position, the auto regeneration inhibit icon appears in the monitor display.



DPF Auto Regeneration Inhibit Switch_002

1 Auto regeneration inhibit icon

DPF Parked Regeneration Switch

⚠ Danger


Since it will become extremely hot around the exhaust outlet, do not perform DPF regeneration in a location where fires may occur.

Important

If parked regeneration is not needed, it will not start, even if the switch is pressed.

The DPF parked regeneration switch is located in the operation panel.


When the regeneration icon is blinking, set the switch to the "Engaged" position to start parked regeneration.



DPF Parked Regeneration Switch_001

1	DPF parked regeneration switch
Α	Engaged

When parked regeneration starts, the regeneration icon in the monitor display changes from blinking to lighting.



DPF Parked Regeneration Switch_002

1 Regeneration icon

Light Switch


A Warning

The lights provide auxiliary lighting.

Do not travel or operate the machine at night or under poor visibility.

The light switch is located in the operation panel.

When the switch is set to the "ON" position, the lights turn on. When it is set to the "OFF" position, the lights turn off.



ight Switch_001

	3 · · · <u>_</u> · ·
1	Light switch
Α	ON
В	OFF

Reel Reverse Switch



Do not switch the reel reverse switch to the "ON" or "OFF" position while the reel cutter (cutting cylinder) is rotating.

Otherwise, a hydraulic system malfunction may result.


Important

If the reel rotation switch is not set to the "ON" position, the reel cutter (cutting cylinder) will not rotate.

This is located under the hood.

This switches the rotation direction of the reel cutter (cutting cylinder).

When the reel reverse switch is set to the "ON" position, the reel cutters (cutting cylinders) of all mower units rotate in reverse (back lapping motion). When the reel reverse switch is set to the "OFF" position, the reel cutters (cutting cylinders) rotate normally.



Reel Reverse Switch_001


1	Reel reverse switch
Α	ON (reverse)
В	OFF (normal rotation)

Reel Rotation/Stop Switching Lever



Before operating the reel rotation/stop switching lever, be sure to set the reel rotation switch to the "OFF" position.

The reel rotation/stop switching lever is located on the reel motor attached to each mower unit. It is used during cutting and back lapping. You must shift only the lever(s) for the mower unit(s) that you plan to use for cutting or back lapping to the "Rotate" position. Leave the lever(s) for other mower units in the "Stop" position.




Reel Rotation/Stop Switching Lever_001

1	Reel rotation/stop switching lever
Α	Rotate
В	Stop

Reel Rotation Adjustment Valve

These valves adjust the rotation speeds of the reel cutters (cutting cylinders).


For #1 and #5



Reel Rotation Adjustment Valve_001

1 Valve for mowers #1 and #5


For #2, #3 and #4



Reel Rotation Adjustment Valve_002

1 Valve for mowers #2, #3 and #4

Reduce the rotation speed by loosening the lock nut, then tightening the knob.
After making adjustments, tighten the lock nut.




Reel Rotation Adjustment Valve_003

1	Knob
2	Lock nut

Mower Lock Lever (Latch)

The mower lock levers (latches) are located in the foot area on the left and right sides and are used when traveling or storing the machine with mower units #4 and #5 raised.

When storing the machine, hook the mower lock levers (latches) on the arms.



Mower Lock Lever (Latch)_001

Mower lock lever (latch)

Mower Unit Up/Down Lever



A Caution

Before raising or lowering the mower units, make sure that there are no people around the machine.




When the mower lock levers (latches) are engaged, do not operate the mower unit up/ down lever.

The mower unit up/down lever is located in the operation panel and raises or lowers the mower units.

When the lever is shifted to the "DOWN" position, the mower units are lowered. When the lever is shifted to the "UP" position, the mower units are raised.

Release the lever to return it to the neutral position.



Mower Unit Up/Down Lever 001

1	Mower unit up/down lever
Α	UP
В	Neutral
С	DOWN

Note:

When the mower units are raised, the reels stop rotating, even if the reel rotation switch is set to the "ON" position.


Throttle Knob

The throttle knob is located to the right of the driver's seat and enables you to adjust the engine rpm.

Move the throttle knob toward the "High speed" position to increase the engine rpm, and toward the "Low speed" position to reduce the rpm.

Note:

The factory default engine rpm (maximum) is set to 2,600 rpm.



Throttle Knob 001

1	Throttle knob
Α	High speed
В	Low speed

Diff-Lock Switch

Note:

Depending on the specifications, this function may not be available.




Do not operate the diff-lock switch unless it is necessary.

It may result in the hydraulic system malfunction.

The diff-lock switch is located below the right side of the steering wheel and engages the differential lock for the left and right front wheels.

Tilt the switch lever up or down to turn "ON" to engage the differential lock for the front wheels.

Release the switch lever to return it to the neutral position ("OFF" position) and disengage the differential lock.



Diff-Lock Switch_001

	1	Diff-lock switch
	Α	ON
	В	OFF

Traveling Pedal




When the machine is traveling at a high speed, it will not stop immediately after you take your foot off the traveling pedal. If necessary, also use the brake.

The traveling pedals are located in the right foot area and control forward and reverse operation of the machine.

When the forward pedal (inside) is depressed, the machine travels forward. When the reverse pedal (outside) is depressed, the machine travels in reverse.

The speed changes in accordance with how much the pedal is depressed.

When you take your foot off the pedal, the machine stops automatically.




Traveling Pedal_001

1	Forward pedal
2	Reverse pedal

Brake Pedal

The brake pedal is located in the left foot area. To stop the machine, depress the brake pedal when needed.



Brake Pedal_001

1	Brake pedal
2	Parking brake lever

Parking Brake Lever



▲ Caution

Be sure to release the parking brake before driving.

It may result in the brakes or hydraulic system malfunction.




A Caution

Never park the machine on a slope.

The parking brake lever is located to the left of the front cover.

When parking, depress the brake pedal, and then pull the parking brake lever completely. To release the parking brake, depress the brake pedals.



Parking Brake Lever 001

1	Brake pedals
2	Parking brake lever

Hood



A Caution

Do not open the hood in strong winds.




A Caution

Be careful not to pinch your fingers when you open or close the hood.

1. Unlock the rubber catch, and then lift up the hood.

2. Hook the hood support rod onto the latch inside the hood.


Make sure that the hood will not close, and then remove your hands.



Hood_001

1	Rubber catch
2	Left hood
3	Hood support rod
4	Right hood

- 3. To close the hood, release the hood support rod from the latch, and then lower the hood slowly.
- 4. Lock the rubber catch securely.



Hood_002


1	Hood
2	Rubber catch

Underseat Cover



Be careful not to pinch your fingers when you open or close the underseat cover.

- 1. Make sure that the steering wheel is raised completely.
- 2. Bring the seat to the backmost position.
- 3. Pull up the lever behind the seat to unlock it.



Underseat Cover_001

1	Lever
2	Seat
Α	Pull up
В	Tilt forward


4. Tilt the seat forward to open the cover. To close the cover, slowly lower the seat.

Instruments

Description of Monitor

The monitor displays various information about the machine, such as the operating status and fault conditions.

The information of desired items can be confirmed according to operating the keys.



Description of Monitor_001

1	Monitor display
2	LED (yellow)
3	LED (red)
4	Enter key
5	Right arrow key
6	Left arrow key
7	Menu key

1. Monitor display

Displays machine conditions and items.

2. LED (yellow)

Lights up when a malfunction is detected, warning not to decrease or stop output.

3. LED (red)

Lights up when a decreased/stopped output malfunction is detected.

4. Enter key

Selects the menu or parameter. Switches between displaying/hiding the current fault code.

5. Right arrow key

Scrolls the screen.

Move the parameter selection to the right or down.

6. Left arrow key

Scrolls the screen.

Move the parameter selection to the left or up.

7. Menu key


Opens or exits the menu.

Main Menu Items

While any parameter is displayed, press the menu key to display the main menu with the following 11 items.

- · GO TO 1-UP DISPLAY / GO TO 4-UP DISPLAY
- · LANGUAGES
- · STORED CODES
- · ENGINE CONFIGURATION
- · SETUP 1-UP DISPLAY
- · SETUP 4-UP DISPLAY
- · SERVICE REMINDERS
- · SELECT UNITS
- · ADJUST BACKLIGHT
- · ADJUST CONTRAST
- · UTILITIES

Page 4-36 Instruments




Main Menu Items_001

Menu key

1-Up Display / 4-Up Display

"GO TO 1-UP DISPLAY" / "GO TO 4-UP DISPLAY" are used to set whether to display parameters individually in a screen or in groups of four per screen.


1. 1-up display
 One parameter is displayed individually in the monitor display.



1-Up Display / 4-Up Display_001

2. 4-up display

Four parameters are displayed in the monitor display. With the 4-up display, a total of 8 parameters are displayed over 2 pages.



1-Up Display / 4-Up Display_002

Note:

The factory default display is the 4-up display. "GO TO 1-UP DISPLAY" appears in the main menu.

When the 1-up display is set, "GO TO 4-UP DISPLAY" appears in the main menu.

Instruments Page 4-37

■Parameter Items

The parameters and corresponding information that appear in the monitor display are listed below.

No.	Monitor display L	Monitor display S	Description
1	ENGINE SPEED	ENG RPM	Displays the engine rpm.
1	DRIVERS DEMAND	ENG REW	Displays the engine rpm.
2	ENGINE TORQUE	DEMAND TQ	Displays the torque required by the ECU.
3	ACTUAL ENGINE TORQUE	ENG TORQ	Displays the actual torque.
4	PERCENT LOAD AT CURRENT RPM	LOAD@RPM	Displays the engine load factor.
5	ACCELERATOR PEDAL POSITION 1	ACCEL PED1	Displays the accelerator sensor opening.
6	ENGINE DESIRED OP SPEED	DES ENG SP	Displays the engine rpm required by the ECU.
7	ENGINE COOLANT TEMPERATURE	COOL TEMP	Displays the temperature measured by the coolant temperature sensor.
8	FUEL RATE	FUEL RATE	Displays the engine fuel consumption rate.
9	THROTTLE POSITION	THROTTLE	Displays the engine throttle opening.
10	BOOST PRESSURE	BST PRES	Displays the pressure measured by the intake pressure sensor.
11	INTAKE MANIFOLD TEMPERATURE	MANI TEMP	Displays the temperature measured by the intake temperature sensor built into the air flow sensor.
12	BATTERY POTENTIAL	BAT VOLT	Displays the battery voltage.
13	BAROMETRIC PRESSURE	BARO PRES	Displays the atmospheric pressure measured by the atmospheric pressure sensor.
14	AMBIENT AIR TEMP	AMB TEMP	Displays the ambient temperature.
15	AIR INLET TEMPERATURE	AIR IN TP	Displays the intake air temperature measured by the air flow sensor.
16	TOTAL FUEL USED	FUEL USED	Displays the total fuel consumption of the engine.
17	TOTAL ENGINE HOURS	ENG HRS	Displays the total time that the ECU is on (time that the key is in the "ON" position).
18	ENGINE OIL PRESSURE	OIL PRES	Displays the engine oil pressure measured by the oil pressure switch. While the engine is running: Normal=200 kPa, Abnormal=0 kPa
19	INJECTOR METERRING RAIL PRESS	RAIL PRES	Displays the fuel pressure in the rail, measured by the rail pressure sensor.
20	ENGINE INLET AIR MASS FLOW RATE	AIR RATE	Displays the intake air volume measured by the air flow sensor.
21	DOC INTAKE GAS TEMP	DOC TEMP	Displays the DOC inlet gas temperature measured by the exhaust temperature sensor.
22	EXHAUST FILTER INLET TEMP	EF IN T	Displays the DPF inlet gas temperature measured by the exhaust temperature sensor.
23	DPF DIFFERENCE PRESSURE	DIFF PRES	Displays the pressure difference before and after the DPF, measured by the differential pressure sensor.

Page 4-38 Instruments

No.	Monitor display L	Monitor display S	Description
24	EXHAUST FILTER OUTLET TEMP	EF OUT T	Displays the DPF outlet gas temperature measured by the exhaust temperature sensor.
25	FE OIII I		Shows the status of the regeneration icon. Icon not displayed="OFF", Icon blinking="ON BLINK", Icon solid="ON SOLID"
26	DPF STATUS	DPF ST	Shows the status of the DPF. DPF regeneration not needed="REGEN NOT NEEDED" DPF regeneration needed=(Level 1="NEEDED LOWEST", Level 2-3="NEEDED MODERATE", Level 4="NEEDED HIGHEST")
27		DPF AR ST	Shows the DPF regeneration status. Regeneration not needed="INACTIVE", Regeneration needed="NEEDED", Regenerating="ACTIVE"
28		INHIBIT ST	Shows the ECU auto regeneration inhibited status. Auto regeneration inhibit switch off="OFF", Auto regeneration inhibit switch on="ON"
29	DPF REGENERATION INHIBITED SW	DPF INHIB SW	Shows the status of auto regeneration inhibit switch. Auto regeneration inhibit switch off="OFF", Auto regeneration inhibit switch on="ON"
30	EXHAUST HIGH TEMP LAMP	EXH T LAMP	Displays the condition of the exhaust temperature. 450 °C or more="ON", 450 °C or less="OFF"
31	%SOOT	%SOOT	Displays the amount of soot accumulated in the DPF.
32	MACHINE HOURS	MACH HRS	Displays the total operating time of the machine (time that the engine was actually running).
33	FUEL LEVEL	FUEL LEVEL	Displays the quantity of fuel remaining in the fuel tank.

Note:

When display settings are being specified, the parameters appear on "Monitor display L". At all other times, the parameters appear on "Monitor display S".


Instruments Page 4-39

Language

With "LANGUAGES", the language used in the monitor display can be set to either of the following two.

- · ENGLISH
- · JAPANESE

An asterisk appears at the right of the currently selected language.



Language_001

1 Asterisk

Note:

The factory default language is "ENGLISH".


Fault Code Log

With "STORED CODES", a log of past fault codes can be checked.

When there is a fault code log, each fault is displayed over two pages.

Use the arrow keys to change the page.


· Text 1



Fault Code Log_001

Arrow keys

· Text 2



Fault Code Log_002

If there is no fault code log, "NO STORED FAULT CODES" appears.

Page 4-40 Instruments

■List of Fault Codes



▲ Caution

When the fault code appears in the monitor display, refer to "Kubota DIAGNOSIS MANUAL COMMON RAIL SYSTEM" or contact your dealer.

The fault codes (DTC) and corresponding information that appear in the monitor display are listed below.

NI-	DTC name	Corrective action	ISO 14229	J1939	-73	Data di ancitana	Behavior during	DTC recovery from
No.	Text 1	Text 2	P-Code	SPN	FMI	Detection item	malfunction	error
1	NE-G phase shift	See Service Manual	P0016	636	7	Large phase shift between NE pulse and G pulse	(Invalid G signal) Slow starting	Diagnostic counter=0
2	Pressure limiter emergency open	See Service Manual	P0087	633	7	Abnormal opening of pressure limiter valve	Insufficient output Deterioration of emission performance	Key switch to "OFF"
3	High rail pressure	See Service Manual	P0088	157	0	Actual pressure exceeds the command pressure (when a high pressure exceeding the operating pressure range is detected)	Insufficient output Deterioration of emission performance	Key switch to "OFF"
4	SCV (MPROP) Stuck	See Service Manual	P0089	1347	7	SCV stuck open (when the actual rail pressure is detected to always exceed the command rail pressure)	Insufficient output Deterioration of emission performance * Engine stopped	Key switch to "OFF"
5	Fuel Leak (in High Pressured Fuel System)	Stop ENG, See Service Manual	P0093	1239	1	Fuel leakage from high-pressure fuel system (when excessive fuel consumption is detected by calculating the difference in the rail pressure before and after fuel injection)	Insufficient output Deterioration of emission performance * Engine stopped	Key switch to "OFF"
6	Intake air temp. error : Low	See Service Manual	P0112	172	4	Ground short circuit of sensor/harness	Increase in white smoke at low temperatures	Diagnostic counter=0
7	Intake air temp. error : High	See Service Manual	P0113	172	3	Circuit interruption or +B short circuit of sensor/harness	Increase in white smoke at low temperatures	Diagnostic counter=0

Page 4-41 Instruments

No.	DTC name	Corrective action	ISO 14229	J1939	-73	Detection item	Behavior during	DTC recovery from
NO.	Text 1	Text 2	P-Code	SPN	FMI	Detection item	malfunction	error
8	Coolant Temperature Sensor Abnormality : Low	See Service Manual	P0117	110	4	Ground short circuit of sensor/harness	Increase in white smoke at low temperatures Insufficient output Deterioration of emission performance	Key switch to "OFF"
9	Coolant Temperature Sensor Abnormality : High	See Service Manual	P0118	110	3	Circuit interruption or +B short circuit of sensor/harness	Increase in white smoke at low temperatures Insufficient output Deterioration of emission performance	Key switch to "OFF"
10	Rail Pressure Sensor Abnormality : Low	Stop ENG, See Service Manual	P0192	157	4	Ground short circuit of sensor/harness Sensor malfunction	Insufficient output Deterioration of emission performance Increase in noise Increase in white smoke Engine stops	Key switch to "OFF"
11	Rail Pressure Sensor Abnormality : High	Stop ENG, See Service Manual	P0193	157	3	Circuit interruption or +B short circuit of sensor/harness Sensor malfunction	Insufficient output Deterioration of emission performance Increase in noise Increase in white smoke Engine stops	Key switch to "OFF"
12	Injector Charge Voltage Abnormality : High	Stop ENG, See Service Manual	P0200	523535	0	Excessive injector charge voltage ECU charge circuit malfunction	Insufficient output Deterioration of emission performance Engine stops	Key switch to "OFF"
13	Open circuit of harness/coil in 1st cylinder injector	See Service Manual	P0201	651	3	Circuit interruption of harness Circuit interruption of injector coil	Insufficient output Increase in vibrations Deterioration of emission performance	Key switch to "OFF"
14	Open circuit of harness/coil in 3rd cylinder injector	See Service Manual	P0202	653	3	Circuit interruption of harness Circuit interruption of injector coil	Insufficient output Increase in vibrations Deterioration of emission performance	Key switch to "OFF"

Page 4-42 Instruments

Nie	DTC name	Corrective action	ISO 14229	J1939	-73	Detection item	Behavior during	DTC recovery from
No.	Text 1	Text 2	P-Code	SPN	FMI	Detection item	malfunction	error
15	Open circuit of harness/coil in 4th cylinder injector	See Service Manual	P0203	654	3	Circuit interruption of harness Circuit interruption of injector coil	Insufficient output Increase in vibrations Deterioration of emission performance	Key switch to "OFF"
16	Open circuit of harness/coil in 2nd cylinder injector	See Service Manual	P0204	652	3	Circuit interruption of harness Circuit interruption of injector coil	Insufficient output Increase in vibrations Deterioration of emission performance	Key switch to "OFF"
17	Engine overheat	Stop mowing!!	P0217	110	0	Abnormally high temperature of engine coolant	Insufficient output Overheating	Diagnostic counter=0
18	Engine overrun	See Service Manual	P0219	190	0	Engine rpm exceeds specified value	Overrunning	Diagnostic counter=0
19	Boost Pressure Sensor Abnormality: Low	See Service Manual	P0237	102	4	Ground short circuit of sensor/harness Sensor malfunction	Insufficient output	Key switch to "OFF"
20	Boost Pressure Sensor Abnormality: High	See Service Manual	P0238	102	3	Circuit interruption or +B short circuit of sensor/harness Sensor malfunction	Insufficient output	Key switch to "OFF"
21	No input of NE sensor pulse	See Service Manual	P0335	636	8	Circuit interruption or short circuit of sensor/ harness Sensor malfunction	(Running only with G) Poor starting Slight increase in vibrations Insufficient output	Key switch to "OFF"
22	NE sensor pulse number error	See Service Manual	P0336	636	2	Circuit interruption or short circuit of sensor/ harness Sensor malfunction	(Running only with G) Poor starting Slight increase in vibrations Insufficient output	Key switch to "OFF"
23	No input of G sensor pulse	See Service Manual	P0340	723	8	Circuit interruption or short circuit of sensor/ harness Sensor malfunction	(Invalid G signal) Slow starting	Diagnostic counter=0
24	G sensor pulse number error	See Service Manual	P0341	723	2	Circuit interruption or short circuit of sensor/ harness Sensor malfunction	(Invalid G signal) Slow starting	Diagnostic counter=0

Instruments Page 4-43

No	DTC name	Corrective action	ISO 14229	J1939	-73	Detection item	Behavior during	DTC recovery from
No.	Text 1	Text 2	P-Code	SPN	FMI	Detection item	malfunction	error
25	Open circuit of glow relay driving circuit	See Service Manual	P0380	676	5	Interruption of glow drive circuit	(At low temperatures) Poor starting Increase in white smoke	Key switch to "OFF"
26	+B short of glow relay driving circuit	See Service Manual	P0380	523544	3	+B short circuit in glow drive circuit	(At low temperatures) Poor starting Increase in white smoke	Key switch to "OFF"
27	Ground short of glow relay driving circuit	See Service Manual	P0380	523544	4	GND short circuit in glow drive circuit	(At low temperatures) Poor starting Increase in white smoke	Key switch to "OFF"
28	Glow Heater Relay Driving Circuit Overheat	See Service Manual	P0381	676	0	Abnormally high temperature of glow drive circuit	(At low temperatures) Poor starting Increase in white smoke	Key switch to "OFF"
29	Oil pressure error	Stop ENG, See Service Manual	P0524	100	1	Oil pressure drop switch activated	Engine stops	Key switch to "OFF"
30	Battery Voltage Abnormality: Low	Stop ENG, See Service Manual	P0562	168	4	Circuit interruption, short circuit or damage of harness Battery malfunction	Poor starting Insufficient output Deterioration of emission performance * Engine stopped	Diagnostic counter=0
31	Battery Voltage Abnormality: High	See Service Manual	P0563	168	3	Circuit interruption, short circuit or damage of harness Battery malfunction	Poor starting Insufficient output Deterioration of emission performance	Key switch to "OFF"
32	QR (IQA) Data Error	Contact dealer	P0602	523538	2	Abnormal QR code correction data	Insufficient output	Diagnostic counter=0
33	No QR (IQA) Data	Contact dealer	P0602	523538	7	QR code correction data unwritten	Insufficient output	Diagnostic counter=0
34	ECU Flash-ROM Error	Stop ENG, See Service Manual	P0605	628	2	Incorrect change in internal flash ROM observed	Engine stops	Key switch to "OFF"
35	ECU CPU (Main IC) Error	Stop ENG, See Service Manual	P0606	1077	2	CPU malfunction or IC malfunction	Engine stops	Key switch to "OFF"
36	ECU CPU (Monitoring IC) Error	Stop ENG, See Service Manual	P0606	523527	2	Malfunction of IC for monitoring CPU	Engine stops	Key switch to "OFF"

Page 4-44 Instruments

No	DTC name	Corrective action	ISO 14229	J1939	-73	Detection item	Behavior during	DTC recovery from
No.	Text 1	Text 2	P-Code	SPN	FMI	Detection item	malfunction	error
37	Injector Charge Voltage Abnormality: Low	Stop ENG, See Service Manual	P0611	523525	1	Insufficient injector charge voltage ECU charge circuit malfunction	Insufficient output Deterioration of emission performance * Engine stopped	Key switch to "OFF"
38	Open Circuit of SCV	Stop ENG, See Service Manual	P0627	1347	5	Circuit interruption of SCV (MPROP)	Insufficient output Deterioration of emission performance	Key switch to "OFF"
39	SCV (MPROP) Drive System Error	Stop ENG, See Service Manual	P0628	1347	4	Ground short circuit of SCV (MPROP)	Insufficient output Deterioration of emission performance Engine stops	Key switch to "OFF"
40	+B Short Circuit of SCV(MPROP)	Stop ENG, See Service Manual	P0629	1347	3	+B short circuit of SCV (MPROP)	Insufficient output Deterioration of emission performance * Engine stopped	Key switch to "OFF"
41	Injector Abnormality	Stop ENG, See Service Manual	P062B	1077	12	Injector drive IC malfunction, full disconnection of COM1TWV drive system, or full disconnection of COM2TWV drive system	Engine stops	Key switch to "OFF"
42	Internal injector drive circuit short	See Service Manual	P062D	523605	6	Short circuit of injector drive IC	Insufficient output Increase in vibrations Deterioration of emission performance * Engine stopped	Key switch to "OFF"
43	Sensor Supply Voltage 1 Abnormality: Low	See Service Manual	P0642	3509	4	Sensor supply voltage 1 error or recognition error	Poor starting Insufficient output Deterioration of emission performance * Engine stopped	Key switch to "OFF"
44	Sensor Supply Voltage 1 Abnormality: High	See Service Manual	P0643	3509	3	Sensor supply voltage 1 error or recognition error	Poor starting Insufficient output Deterioration of emission performance * Engine stopped	Key switch to "OFF"

No.	DTC name	Corrective action	ISO 14229	J1939	-73	Detection item	Behavior during	DTC recovery from
INU.	Text 1	Text 2	P-Code	SPN	FMI	Detection item	malfunction	error
45	Sensor Supply Voltage 2 Abnormality: Low	See Service Manual	P0652	3510	4	Sensor supply voltage 2 error or recognition error	Poor starting Insufficient output Deterioration of emission performance	Key switch to "OFF"
46	Sensor Supply Voltage 2 Abnormality: High	See Service Manual	P0653	3510	3	Sensor supply voltage 2 error or recognition error	Poor starting Insufficient output Deterioration of emission performance	Key switch to "OFF"
47	Sensor Supply Voltage 3 Abnormality: Low	See Service Manual	P0662	3511	4	Sensor supply voltage 3 error or recognition error	Poor starting	Key switch to "OFF"
48	Sensor Supply Voltage 3 Abnormality: High	See Service Manual	P0662	3511	3	Sensor supply voltage 3 error or recognition error	Poor starting	Key switch to "OFF"
49	Main relay is locked in closed position	See Service Manual	P0687	1485	2	Main relay malfunction	Battery discharged	Key switch to "OFF"
50	Gnd Short Circuit of Start Relay Driving Circuit	See Service Manual	P081A	677	4	Ground short circuit of starter relay drive circuit		Key switch to "OFF"
51	Accelerator Position Sensor 1 Abnormality: Low	See Service Manual	P2122	91	4	Circuit interruption or ground short circuit of sensor/harness	Insufficient output	Diagnostic counter=0
52	Accelerator Position Sensor 1 Abnormality: High	See Service Manual	P2123	91	3	Power supply short circuit of sensor/ harness	Insufficient output	Diagnostic counter=0
53	Accelerator Position Sensor 2 Abnormality: Low	See Service Manual	P2127	29	4	Circuit interruption or ground short circuit of sensor/harness	Insufficient output	Diagnostic counter=0
54	Accelerator Position Sensor 2 Abnormality: High	See Service Manual	P2128	29	3	Power supply short circuit of sensor/ harness	Insufficient output	Diagnostic counter=0
55	Accelerator Position Sensor Error (CAN)	See Service Manual	P2131	523543	2	Abnormal message received from machine	Insufficient output	Diagnostic counter=0 (Immediate recovery after normal recovery of CAN signal)
56	No.1 & 4 cylinder injector short to +B	Stop ENG, See Service Manual	P2148	523523	3	+B short circuit or GND short circuit of harness	Insufficient output Increase in vibrations Deterioration of emission performance * Engine stopped	Key switch to "OFF"

Page 4-46 Instruments

No	DTC name	Corrective action	ISO 14229	J1939	-73	Detection item	Behavior during	DTC recovery from
No.	Text 1	Text 2	P-Code	SPN	FMI	Detection item	malfunction	error
57	No.2 & 3 cylinder injector short to +B	Stop ENG, See Service Manual	P2151	523524	3	+B short circuit or GND short circuit of harness	Insufficient output Increase in vibrations Deterioration of emission performance * Engine stopped	Key switch to "OFF"
58	Barometric Pressure Sensor Error: Low	See Service Manual	P2228	108	4	Ground short circuit of sensor/internal ECU circuit	Insufficient output	Diagnostic counter=0
59	Barometric Pressure Sensor Error: High	See Service Manual	P2229	108	3	+B short circuit of sensor/internal ECU circuit	Insufficient output	Diagnostic counter=0
60	Pressure limiter not open	Stop ENG, See Service Manual	P2293	679	7	Stuck P/L valve P/L valve cannot open (with low engine output)	Engine stops	Key switch to "OFF"
61	Rail Pressure Sensor Abnormality After P/L Open	Stop ENG, See Service Manual	P2293	679	16	Rail pressure too high or too low after P/L valve opened	Engine stops	Key switch to "OFF"
62	CAN1 Bus off	See Service Manual	U0077	523604	2	CAN1 +B/GND short circuit or high traffic malfunction	Insufficient output * Transmission data NG	Key switch to "OFF"
63	CAN2 Bus off	See Service Manual	U0075	523547	2	CAN2 +B/GND short circuit or high traffic malfunction	Insufficient output * Transmission data NG	Key switch to "OFF"
64	CAN-KBT Frame error	See Service Manual	U0081	523548	2	Circuit interruption of CAN_KBT original frame	Insufficient output	Key switch to "OFF"
65	Intake air temp. built-in MAF sensor abnormality: Low	See Service Manual	P0072	171	4	Ground short circuit of sensor/harness	-	Diagnostic counter=0
66	Intake air temp. built-in MAF sensor abnormality: High	See Service Manual	P0073	171	3	Circuit interruption of sensor/harness +B short circuit of sensor/harness	-	Diagnostic counter=0
67	Intake Air Volume: Low	See Service Manual	P0101	132	1	Insufficient intake (turboblower IN hose disconnected)	Insufficient output	Key switch to "OFF"
68	MAF Sensor Abnormality: Low	See Service Manual	P0102	132	4	Circuit interruption of sensor/harness Ground short circuit of sensor/harness	Insufficient output Deterioration of emission performance	Key switch to "OFF"

No	DTC name	Corrective action	ISO 14229	J1939	-73	Detection item	Behavior during	DTC recovery from
No.	Text 1	Text 2	P-Code	SPN	FMI	Detection item	malfunction	error
69	MAF Sensor Abnormality: High	See Service Manual	P0103	132	3	+B short circuit of sensor/harness	Insufficient output Deterioration of emission performance	Key switch to "OFF"
70	EGR actuator open circuit	See Service Manual	P0403	523574	3	Circuit interruption of EGR motor coil	Insufficient output Deterioration of emission performance	Key switch to "OFF"
71	EGR actuator coil short	See Service Manual	P0404	523574	4	Short circuit of EGR coil	Insufficient output Deterioration of emission performance	Key switch to "OFF"
72	EGR position sensor failure	See Service Manual	P0409	523572	4	EGR position sensor malfunction	Insufficient output Deterioration of emission performance	Key switch to "OFF"
73	Exhaust gas temp. sensor 1 (T1) abnormality: Low	See Service Manual	P0543	3242	4	Ground short circuit of sensor/harness	None	Key switch to "OFF"
74	Exhaust gas temp. sensor 1 (T1) abnormality: High	See Service Manual	P0544	3242	3	Circuit interruption of sensor/harness +B short circuit of sensor/harness	None	Key switch to "OFF"
75	Exhaust Gas Temp. Sensor 0 (T0) Abnormality: Low	See Service Manual	P0546	4765	4	Ground short circuit of sensor/harness	None	Key switch to "OFF"
76	Exhaust Gas Temp. Sensor 0 (T0) Abnormality: High	See Service Manual	P0547	4765	3	Circuit interruption of sensor/harness +B short circuit of sensor/harness	None	Key switch to "OFF"
77	EEPROM check sum error	See Service Manual	P1990	523700	13	KBT EEPROM Checksum discrepancy	None	Key switch to "OFF"
78	Intake throttle feedback error	See Service Manual	P2108	523580	2	Abnormal feedback of intake throttle DC motor	None	Key switch to "OFF"
79	Accelerator position sensor correlation error	See Service Manual	P2135	91	2	Excessive discrepancy in output of two sensors	Insufficient output	Diagnostic counter=0
80	EGR actuator valve stuck	See Service Manual	P2413	523575	7	Stuck EGR valve	Insufficient output Deterioration of emission performance	Key switch to "OFF"

Page 4-48 Instruments

No.	DTC name	Corrective action	ISO 14229	J1939	-73	Detection item	Behavior during	DTC recovery from
INO.	Text 1	Text 2	P-Code	SPN	FMI	Detection item	malfunction	error
81	EGR (DC motor) Overheat	See Service Manual	P2414	523576	2	Abnormally high temperature of EGR motor	Insufficient output Deterioration of emission performance	Key switch to "OFF"
82	EGR (DC motor) temp. sensor failure	See Service Manual	P2415	523577	2	Malfunction of EGR motor temperature sensor	Insufficient output Deterioration of emission performance	Key switch to "OFF"
83	Exhaust Gas Temp. Sensor 2 (T2) Abnormality: Low	See Service Manual	P242C	3246	4	Ground short circuit of sensor/harness	None	Key switch to "OFF"
84	Exhaust Gas Temp. Sensor 2 (T2) Abnormality: High	See Service Manual	P242D	3246	3	Circuit interruption of sensor/harness +B short circuit of sensor/harness	None	Key switch to "OFF"
85	Differential Pressure Sensor 1 Abnormality: Low	See Service Manual	P2454	3251	4	Ground short circuit of sensor/harness	None	Key switch to "OFF"
86	Differential Pressure Sensor 1 Abnormality: High	See Service Manual	P2455	3251	3	Circuit interruption of sensor/harness +B short circuit of sensor/harness	None	Key switch to "OFF"
87	Intake Throttle Lift Sensor Abnormality: Low	See Service Manual	P2621	523582	4	Intake throttle lift sensor low	None	Key switch to "OFF"
88	Intake Throttle Lift Sensor Abnormality: High	See Service Manual	P2622	523582	3	Intake throttle lift sensor high	None	Key switch to "OFF"
89	Emission deterioration	See Service Manual	P3001	3252	0	Abnormally high DOC temperature due to uncombusted fuel	Insufficient output	Key switch to "OFF"
90	Exhaust Gas Tempe. Sensor 0 Emergency High	Stop ENG, See Service Manual	P3002	4765	0	Abnormally high DOC inlet temperature (T0)	Engine stops * Cannot start until 300 °C or less	Exhaust temperature sensor is 300 °C or less and key switch to "OFF"
91	Exhaust Gas Tempe. Sensor 1 Emergency High	Stop ENG, See Service Manual	P3003	3242	0	Abnormally high DPF inlet temperature (T1)	Engine stops * Cannot start until 300 °C or less	Exhaust temperature sensor is 300 °C or less and key switch to "OFF"
92	Exhaust Gas Tempe. Sensor 2 Emergency High	Stop ENG, See Service Manual	P3004	3246	0	Abnormally high DPF outlet temperature (T2)	Engine stops * Cannot start until 300 °C or less	Exhaust temperature sensor is 300 °C or less and key switch to "OFF"

No.	DTC name	Corrective action	ISO 14229	J1939	-73	Detection item	Behavior during	DTC recovery from
INO.	Text 1	Text 2	P-Code	SPN	FMI	Detection item	malfunction	error
93	Excessive PM3	Start DPF Parked Regeneration immediately	P3006	3701	15	Excessive accumulation of PM (estimate)-Level 3	Insufficient output	Diagnostic counter=0
94	Excessive PM4	Stop engine!! Contact dealer immediately	P3007	3701	16	Excessive accumulation of PM (estimate)-Level 4	Insufficient output	Diagnostic counter=0
95	Excessive PM5	Stop engine!! Contact dealer immediately	P3008	3701	0	Excessive accumulation of PM (estimate)-Level 5	Insufficient output	Key switch to "OFF" (Reset by service tool)
96	Boost pressure low	See Service Manual	P3011	132	15	Hose disconnected between turboblower OUT and intake flange Boost pressure sensor malfunction	Insufficient output	Key switch to "OFF"
97	Low Coolant Temp. in Parked Regeneration	See Service Manual	P3012	523589	17	Engine warm-up conditions not met during regeneration (insufficient coolant temperature increase)	None	Diagnostic counter=0 (Press manual regeneration button again.)
98	Parked regeneration time out	See Service Manual	P3013	523590	16	Regeneration does not end without an increase in DPF temperature	None	Diagnostic counter=0 (Press manual regeneration button again.)
99	All Exhaust Gas Temp. Sensor Failure	See Service Manual	P3018	523599	0	Simultaneous circuit interruption of all exhaust temperature sensors	None	Diagnostic counter=0
100	High Exhaust Gas Temperature After Emergency High Temp. DTC	Stop ENG, See Service Manual	P3023	523601	0	Exhaust temperature when a high exhaust temperature malfunction occurred	None Engine stops	Diagnostic counter=0
101	High frequency of regeneration	See Service Manual	P3024	523602	0	Abnormal interval from the end of regeneration until the next regeneration is triggered	Deterioration of emission performance * NOx increase	Key switch to "OFF" (Reset by service tool)
102	Over heat pre- caution	Stop mowing!!	P3025	523603	15	Coolant temperature	Deterioration of emission performance	Diagnostic counter=0
103	No communication with EGR	See Service Manual	U0076	523578	2	Interruption of communication between EGR and CAN	Insufficient output Deterioration of emission performance	Key switch to "OFF"
104	CAN CCVS frame error	See Service Manual	U0082	523591	2	Interruption of communication	None	Key switch to "OFF"

Page 4-50 Instruments

	DTC name	Corrective action	ISO 14229	J1939	-73		Behavior during	DTC recovery from
No.	Text 1	Text 2	P-Code	SPN	FMI	Detection item	malfunction	error
104	CAN CCVS frame error	See Service Manual	U0082	523591	2	between CAN and CCVS	None	Key switch to "OFF"
105	CAN CM1 frame error	See Service Manual	U0083	523592	2	Interruption of communication between CAN and CM1	None	Key switch to "OFF"
106	CAN ETC5 frame error	See Service Manual	U0086	523595	2	Interruption of communication between CAN and ETC5	None	Key switch to "OFF"
107	CAN TSC1 frame error	See Service Manual	U0087	523596	2	Abnormal interruption of communication between CAN and TSC1	None	Diagnostic counter=0
108	CAN EBC1 frame error	See Service Manual	U0089	523598	2	Abnormal interruption of communication between CAN and EBC1	None	Diagnostic counter=0
109	FUEL LEVEL LOW	Refuel		96	17	Remaining fuel volume at specified value or less (factory default setting=10%) Can be adjusted between 10% and 80%	None	Supply fuel until remaining fuel volume reaches the specified value or above

Engine Configuration

This function is not supported.

1-Up Display Setup

With "SETUP 1-UP DISPLAY", the displayed parameters can be reset to the factory defaults, or the necessary parameters to be displayed can be selected.


The following 3 items appear when "SETUP 1-UP DISPLAY" is selected.

- · USE DEFAULTS
- · CUSTOM SETUP
- · AUTOMATIC SCAN

■Use Defaults

With "USE DEFAULTS", the 1-up display parameters return to the factory defaults.


1. Press the menu key. After the main menu appears, use the arrow keys to highlight "SETUP 1-UP DISPLAY", and then press the Enter key.



Use Defaults_001

1	Menu key
2	Arrow keys
3	Enter key

2. Highlight "USE DEFAULTS", and then press the Enter key.




Use Defaults_002

- 3. "RESTORED TO DEFAULTS" appears in the monitor display, and the parameters are reset to the factory defaults of the following 8 items.
 - [1] ENGINE SPEED
 - [2] ENGINE COOLANT TEMPERATURE
 - [3] %SOOT
 - [4] FUEL LEVEL
 - [5] ENGINE OIL PRESSURE
 - [6] MACHINE HOURS
 - [7] BATTERY POTENTIAL
 - [8] DPF STATUS
- 4. After the settings have been applied, pressing the menu key once returns to the main menu, and pressing the key again returns to the 1-up/4-up display screen.

Custom Setup

With "CUSTOM SETUP", the type and number of parameters as well as their display order can be specified.

1. Press the menu key. After the main menu appears, use the arrow keys to highlight "SETUP 1-UP DISPLAY", and then press the Enter key.




Custom Setup_001

1	Menu key
2	Arrow keys
3	Enter key

Page 4-52 Instruments

Highlight "CUSTOM SETUP", and then press the Enter key. The list of parameters appears.




Custom Setup_002

- 3. Change the parameters.
 - [1] To add a parameter
 - a. Use the arrow keys to highlight the parameter to be added, and then press the Enter key.




Custom Setup_003

b. A number appears at the right of the selected parameter. This number indicates the display order for the parameter




Custom Setup_004

- [2] To deselect a parameter and remove it from the list of displayed parameters
 - a. Highlight the parameter, and then press the Enter key.



Custom Setup_005

b. Check that the number at the right of the parameter disappeared.




Custom Setup_006

4. After the settings have been applied, pressing the menu key once returns to the main menu, and pressing the key again returns to the 1-up/4-up display screen.

■Automatic Scan

With "AUTOMATIC SCAN", the 1-up display can be set to automatically scroll through the selected parameters one by one.


 Press the menu key.
 After the main menu appears, use the arrow keys to highlight "SETUP 1-UP DISPLAY", and then press the Enter key.



Automatic Scan_001

1	Menu key
2	Arrow keys
3	Enter key

2. When "AUTOMATIC SCAN ON" appears, the parameters are scrolled automatically. For manual scrolling, highlight "AUTOMATIC SCAN ON", and then press the Enter key. It turns into "AUTOMATIC SCAN OFF" and the parameters will be scrolled



Automatic Scan_002

3. After the settings have been applied, pressing the menu key once returns to the main menu, and pressing the key again returns to the 1-up/4-up display screen.

Note:

When the parameters are scrolled automatically, press the Enter key once to pause scrolling.

When scrolling is paused, press the Enter key once to restart scrolling.

4-Up Display Setup


With "SETUP 4-UP DISPLAY", the displayed parameters can be reset to the factory defaults, or the monitor display of selected, necessary parameters can be set up. The following 2 items appear when "SETUP 4-UP DISPLAY" is selected.

- · USE DEFAULTS
- · CUSTOM SETUP

■Use Defaults

With "USE DEFAULTS", the 4-up display parameters return to the factory defaults.

Press the menu key.
 After the main menu appears, use the arrow keys to highlight "SETUP 4-UP DISPLAY", and then press the Enter key.




Use Defaults_001

1	Menu key
2	Arrow keys
3	Enter key

Page 4-54 Instruments

2. Highlight "USE DEFAULTS", and then press the Enter key.




Use Defaults_002

- "RESTORED TO DEFAULTS" appears in the monitor display, and the parameters are reset to the factory defaults of the following 8 items.
 - · First page
 - [1] ENGINE SPEED
 - [2] ENGINE COOLANT TEMPERATURE
 - [3] %SOOT
 - [4] FUEL LEVEL
 - · Second page
 - [1] ENGINE OIL PRESSURE
 - [2] MACHINE HOURS
 - [3] BATTERY POTENTIAL
 - [4] DPF STATUS
- 4. After the settings have been applied, pressing the menu key once returns to the main menu, and pressing the key again returns to the 1-up/4-up display screen.
- ■Custom Setup

With "CUSTOM SETUP", the type and number of parameters as well as their display order can be specified.


 Press the menu key. After the main menu appears, use the arrow keys to highlight "SETUP 4-UP DISPLAY", and then press the Enter key.



Custom Setup_001


1	Menu key
2	Arrow keys
3	Enter key

2. Highlight "CUSTOM SETUP", and then press the Enter key.



Custom Setup_002

- Select the page.
 - [1] Check that the values for the four parameters are highlighted.




Custom Setup_003

[2] Use the arrow keys to display the page to be changed, and then press the Enter key.

Parameter values


- 4. Change the parameters.
 - [1] Check that the value for one parameter is highlighted.




Custom Setup_004

- [2] Use the arrow keys to highlight the value of the parameter to be changed, and then press the Enter key.
- [3] The parameters appear.


 The number at the right of the parameter indicates the location in the 4-up display.
 - 1=Upper left
 - 2=Lower left
 - 3=Upper right
 - 4=Lower right






Custom Setup_006

- [4] To change to a different parameter
 - a. Use the arrow keys to highlight the parameter to be selected, and then press the Enter key.




Custom Setup_007

b. Check that a number appeared to the right of the selected parameter.



Custom Setup_008


c. Press the menu key and check that the parameter has changed.



Custom Setup_009

Page 4-56 Instruments

- [5] To deselect a parameter and remove it from the list of displayed parameters
 - a. Highlight the parameter to be removed, and then press the Enter key.




Custom Setup_010

b. Check that the number at the right of the parameter disappeared.



Custom Setup_011

c. Press the menu key and check that the parameter has changed to "EMPTY".



Custom Setup_012

- 5. Pressing the menu key once returns to the display for selecting the page.
- 6. To change other parameters, repeat steps 3 to 5.

Service Reminders

With "SERVICE REMINDERS", the notification of replacement time for the following 5 consumables can be specified.

- · Engine oil
- · Engine oil filter
- · Hydraulic oil
- · Hydraulic oil filter
- · Air cleaner


The following 2 items appear when "SERVICE REMINDERS" is selected.

- · RESET REMINDERS
- · MODIFY REMINDERS

■Reset Reminders

With "RESET REMINDER", displayed remaining time can be reset to the time specified with "MODIFY REMINDERS".


Press the menu key.
 After the main menu appears, use the arrow keys to highlight "SERVICE REMINDERS", and then press the Enter key.



Reset Reminders_001


1	Menu key
2	Arrow keys
3	Enter key

2. Highlight "RESET REMINDER", and then press the Enter key.



Reset Reminders_002

Use the arrow keys to highlight the item to be changed, and then press the Enter key. A plus appears at the right of the currently selected items.



Reset Reminders_003

1 Plus

4. The remaining time for the selected item appears.




Reset Reminders 004

[1] To reset the remaining time to the specified time, press the Enter key.

[2] "RESET SERVICE REMINDER?" appears.

To reset, press the Enter key.
To cancel resetting, press the menu key.




Reset Reminders_005

- 5. The screen for selecting the item appears.
- ■Modify Reminders

With "MODIFY REMINDERS", the replacement time period for consumables can be specified.

Press the menu key.
 After the main menu appears, use the arrow keys to highlight "SERVICE REMINDERS", and then press the Enter key.




Modify Reminders_001

1	Menu key
2	Arrow keys
3	Enter key


Page 4-58 Instruments

2. Highlight "MODIFY REMINDERS", and then press the Enter key.



Modify Reminders_002


Use the arrow keys to highlight the item to be changed, and then press the Enter key. A plus appears at the right of the currently specified items.



Modify Reminders_003


1 Plus

4. The replacement time period for the selected item appears.



Modify Reminders 004

 Highlight the digit to be changed.
 Press the right arrow key to increase the number. Press the left arrow key to change the digit.



Modify Reminders_005

1	Right arrow key
2	Left arrow key

- 6. To save the specified time period, press the Enter key.
- "MODIFY SERVICE REMINDER?" appears.

To save the changes, press the Enter key. To cancel the changes, press the menu key.



Modify Reminders_006

8. The display for selecting the item appears. Initial and regular time periods

	Initial time period	Regular time period
Engine oil	50 hrs.	400 hrs.
Engine oil filter	50 hrs.	400 hrs.
Hydraulic oil	100 hrs.	500 hrs.
Hydraulic oil filter	100 hrs.	500 hrs.
Air cleaner	600 hrs.	600 hrs.

Note:


The factory default replacement time periods are the initial time periods.

■Reminder Display



If a warning message appears, immediately stop operation, and then perform the replacement procedure.


 When the specified replacement time period for a consumable has passed, a warning message appears in the monitor display and the LED (yellow) lights up.



Reminder Display_001

1	LED (yellow)
2	Enter key

- 2. Pressing the Enter key changes the screen from the warning message to the parameter display.
- 3. A warning mark appears in the upper-right corner of the monitor display.



Reminder Display_002

1 Warning mark


 Change the replacement time period of consumables with "RESET REMINDERS" or "MODIFY REMINDERS".
 When the replacement time period is changed, the warning message and mark disappear.

Select Units

With "SELECT UNITS", the units of parameter values can be set to any of the following three formats.

- · ENGLISH
- · METRIC KPA
- · METRIC BAR

An asterisk appears at the right of the currently selected unit.



Select Units 001

1 Asterisk

Page 4-60 Instruments


	Units		
Monitor display S	ENGLIS		METRI
	Н	C KPA	C BAR
ENG RPM	RPM	RPM	RPM
DEMAND TQ	%	%	%
ENG TORQ	%	%	%
LOAD@RPM	%	%	%
ACCEL PED1	%	%	%
DES ENG SP	RPM	RPM	RPM
COOL TEMP	F	С	С
FUEL RATE	G/HR	L/HR	L/HR
THROTTLE	%	%	%
BST PRES	PSI	kPa	BAR
MANI TEMP	F	С	С
BAT VOLT	VDC	VDC	VDC
BARO PRES	PSI	kPa	BAR
AMB TEMP	F	С	С
AIR IN TP	F	С	С
FUEL USED	Gal	L	L
ENG HRS	Н	Н	Н
OIL PRES	PSI	kPa	BAR
RAIL PRES	PSI	kPa	BAR
AIR RATE	Gal	L	L
DOC TEMP	F	С	С
EF IN T	F	С	С
DIFF PRES	PSI	kPa	BAR
EF OUT T	F	С	С
%SOOT	%	%	%
MACH HRS	Н	Н	Н
FUEL LEVEL	%	%	%

Note:

The factory default unit is "METRIC KPA".

Adjust Backlight

With "ADJUST BACKLIGHT", the brightness of the monitor display can be adjusted. Press the right arrow key to make the display brighter. Press the left arrow key to make the display darker.




Adjust Backlight_001

1	Right arrow key
2	Left arrow key

Adjust Contrast

With "ADJUST CONTRAST", the contrast of the monitor display can be adjusted. Press the right arrow key to decrease the contrast. Press the left arrow key to increase the contrast.



Adjust Contrast_001

1	Right arrow key
2	Left arrow key

Utilities

With "UTILITIES", the remaining fuel volume can be specified and the monitor configuration can be displayed.

The following 6 items appear when "UTILITIES" is selected.

- · GAGE DATA
- · REMOVE ALL GAGES
- · SOFTWARE VERSION
- · FAULT CONVERSION
- · ANALOG INPUT
- · OEM

Note:

"GAGE DATA" and "REMOVE ALL GAGES" are not supported on this machine.

■Software Version

With "SOFTWARE VERSION", the software version of the monitor can be displayed.

■Fault Conversion

With "FAULT CONVERSION", the J1939 fault code conversion method can be specified.

The monitor normally detects J1939 version 4

Since the engine ECU of this machine uses J1939 version 4, no adjustments are necessary.

Analog Input

With "ANALOG INPUT", remaining fuel volume information can be specified. The following 2 items appear when "ANALOG INPUT" is selected.


- · BACKLIGHT DIMMER
- · FUEL LEVEL

Important

"BACKLIGHT DIMMER" is not supported on this machine.

Always select "FUEL LEVEL".

If "BACKLIGHT DIMMER" is selected, "NO DATA" appears as the value for the fuel level parameter.



Analog Input_001


Note:

The factory default analog input is "FUEL LEVEL".

Fuel Level

With "FUEL LEVEL", the low fuel level can be specified.

Press the menu key.
 After the main menu appears, use the arrow keys to highlight "UTILITIES", and then press the Enter key.




Fuel Level_001

1	Menu key
2	Arrow keys
3	Enter key


Page 4-62 Instruments

2. Highlight "ANALOG INPUT", and then press the Enter key.




Fuel Level_002

3. Highlight "FUEL LEVEL", and then press the Enter key.




Fuel Level_003

4. Highlight "SET LOW FUEL LEVEL", and then press the Enter key.



Fuel Level_004

5. "LOW FUEL" appears.



Fuel Level_005

- 6. Press the right arrow key to increase the value. Press the left arrow key to decrease the value.
 - The value can be set between 10% and 80% in 5% increments.
- 7. To save the specified value, press the Enter key.

Note:

The factory default low fuel level is 10%.

Low Fuel Level Display




If a warning message appears, immediately stop operation, and then supply fuel.

 When the fuel level falls below the specified low fuel level, a warning message appears in the monitor display and the LED (yellow) lights up. The warning message appears on two pages.

Use the arrow keys to change the page.

. Tavt 1



Low Fuel Level Display 001


1	LED (yellow)
2	Enter key
3	Arrow keys

· Text 2



Low Fuel Level Display_002

- 2. Pressing the Enter key changes the screen from the warning message to the parameter display.
- 3. A warning mark appears in the upperright corner of the monitor display.



Low Fuel Level Display 003

Warning mark

4. When fuel is supplied to bring the fuel level above the specified low fuel level, the warning message and mark disappear.

■OEM

"OEM" is used when the manufacturer specifies factory default settings.

Important

No adjustments by the operator are necessary.

Travel of Machine

Moving the Machine



▲ Caution

When traveling, be sure to stop the reel cutters and raise the mower units.

- 1. Start the engine.
 - "Procedure to Start Engine" (Page 4-23)
- 2. Raise all mower units, and then engage the mower lock levers (latches) for mower units #4 and #5.
- 3. Depress the brake pedal to release the parking brake.
- Slowly depress the traveling pedal.
- 5. The machine will start to move.

Towing the Machine

If the machine does not travel due to engine trouble, etc., you can move it by towing it.



Tow the machine at a low speed while paying close attention.



▲ Caution

Do not touch the unload valve except when towing the machine.




Caution

Before restarting the engine, be sure to close the unload valve.

- 1. Stop the engine.
 - "Procedure to Stop Engine" (Page 4-24)
- 2. Apply the parking brake and chock the wheels.
- 3. Set the 2WD/4WD selector switch to the "2WD" position.
- Make sure that the steering wheel is raised completely.

Page 4-64 Travel of Machine


5. Pull up the forward/backward adjustment lever, and then slide the seat backward completely.



Towing the Machine_001

1	Forward/backward adjustment lever
2	Seat


6. While pulling up the lever behind the seat, tilt the seat forward.



Towing the Machine_002

1	Lever
2	Seat
Α	Pull up
В	Tilt forward

7. Turn the unload valve, located beside the hydraulic pump, 90 degrees (so that it is vertical) to open it.



Towing the Machine_003

Unload valve

- 8. Remove the wheel stopper, and then depress the brake pedal to release the parking brake.
- 9. Tow the machine slowly.

Cutting Work

Cutting Work



Do NOT start to move or stop the machine abruptly.

To do so is very dangerous. In addition, it may damage the hydraulic system or result in oil leakage.

▲ Caution

Cutting work must be performed at an appropriate speed for the site and location. When cutting over bumpy surfaces, keep the engine rpm steady, and slow down the cutting speed.




Reel rotation will be turned on or off based on the sensor-detected position of the mower units.

Please note that if you stop operating the mower unit up/down lever before the mower units are raised completely, reel rotation may not stop.

- 1. Drive to the cutting area.
 "Moving the Machine" (Page 4-64)
- Move the throttle knob to the "High speed" position to run the engine at the maximum rpm.
- 3. Right before starting cutting work, release the mower lock levers for mower units #4 and #5.

Cutting Work Page 4-65

4. Shift the mower unit up/down lever to the "DOWN" position to lower the mower units.



Cutting Work_001


1	Mower unit up/down lever
Α	UP
В	Neutral
С	DOWN



When the engine rotation is at low speed, do not rotate the knives.

It may result in the hydraulic system malfunction.

5. Set the reel rotation switch to the "ON" position to rotate the reel cutters (cutting cylinders) of all mower units.



Cutting Work 002

1	Reel rotation switch
Α	ON
В	OFF

Depress the traveling pedal to start cutting work.

Note:

During the work, the reel cutters (cutting cylinders) will rotate or stop in sync with the up and down motion of the mower units.

Transporting

Transporting Procedure

When loading the machine into a trailer or a truck to transport it, drive the machine forward. When unloading, drive the machine in reverse. If the roof is installed on the machine, remove it.

The roof may be damaged by wind pressure.

Page 4-66 Transporting

Maintenance Precautions	Page 5-2
Maintenance Schedule	Page 5-3
Specified Values	Page 5-8
DPF	Page 5-9
About DPF Types of DPF Regeneration Conditions for DPF Regeneration DPF Regeneration Displays DPF Auto Regeneration	Page 5-9 Page 5-10 Page 5-10
Jacking up the machine	Page 5-15
About the Jacking up the machine Jack-up Points	-
Greasing	Page 5-16
About GreasingGreasing Points	
Maintenance (Mower)	Page 5-22
Back Lapping of Reel Cutter (Cutting Cylinder)	
	_
Swiveling Mower Units #2 and #3 Removing/Installing Tires Adjustment of Belt Tension Adjustment of Brake Adjusting the Neutral Position of the	Page 5-25 Page 5-26
Piston Pump	Page 5-28
Change of Fuse	Page 5-29
Long-Term Storage	Page 5-29
Before Long-Term Storage	Page 5-29

Maintenance Precautions



A Caution

First, learn well the maintenance operations you plan to perform.



A Caution

Use tools appropriate for each maintenance operation.



A Caution

For the safe and best performance of your machine, use Baroness genuine parts for replacement and accessories.

Please note that our product warranty may be void if you use non-genuine parts for replacement or accessories.

Maintenance Schedule

LM3210

Follow the maintenance schedule below.

O · · · Inspect, adjust, supply, clean

• • • Replace (first time)

 $\triangle \cdot \cdot \cdot$ Replace

	rtopiaco																	
	Maintenance Item	Before Work	After Work	Every Week	Every 50 hrs.	Every 100 hrs.	Every 250 hrs.	Every 400 hrs.	Every 500 hrs.	Every 800 hrs.	Every 1000 hrs.	Every 1500 hrs.	Every 3000 hrs.	Every year	Every 2 years	Every 4 years	When Required	Remarks
*5	Check engine oil level and contamination	0																
*5	Check fuel level	0																
*5	Check coolant level	0																
*5	Check fan belt	0																
	Check hydraulic oil level	0																Refer to "Inspection of Hydraulic Oil"
	Check tire pressures and condition	0																Refer to "Inspection of Tires"
	Check blade condition (Reel cutter and Bed knife)	0																Refer to "Inspection of Reel Cutter (Cutting Cylinder) and Bed Knife (Bottom Blade)"
	Check roller condition	0																
	Engage blades	0																
	Check mowing height	0																
	Check interlock system safety function	0																
	Check oil or water leaks	0																Refer to "Inspection of Oil Leakage"
	Check cover condition	0																
	Check damaged parts	0																
	Check tightening bolts and nuts	0																
	Check brake function	0																Refer to "Inspection of Brake"
	Check hydraulic hoses condition	0																
	Clean machine exterior		0															

Maintenance Schedule Page 5-3

	Maintenance Item	Before Work	After Work	Every Week	Every 50 hrs.	Every 100 hrs.	Every 250 hrs.	Every 400 hrs.	Every 500 hrs.	Every 800 hrs.	Every 1000 hrs.	Every 1500 hrs.	Every 3000 hrs.	Every year	Every 2 years	Every 4 years	When Required	Remarks
	Clean engine area		0															On an valva
	Open air cleaner evacuator valve to remove dust		0	0														Open valve every week or daily in dusty conditions
	Clean radiator core		0															
	Clean oil cooler core		0															
*5	Check fuel hoses and clamp bands				0													
*5	Draining of water separator				0													Refer to "Draining of Water Separator"
	Grease and Lubricate all moving parts				0													Refer to "Greasing Points"
	Grease rear mower unit swing out pins				0													
	Check CR brush condition				0													only if fitted
	Clean inside of CR brush belt cover				0													only if fitted
	Check and Adjust brakes				0													
	Grease mower unit hydraulic motor shafts						0											
	Grease cutting reel pivot pins (Axis bolt)								0									
*5	Clean air cleaner outer element (Replace the element after 6-time cleaning)					0								Δ				Replace every 6 cleanings or every year whichever comes earlier Air cleaner should be cleaned more often in dusty conditions than in normal conditions
	Replace hydraulic oil					•			Δ									100 hours first change, every 500 hours thereafter
	Replace hydraulic oil filter					•			Δ									100 hours first change, every

Page 5-4 Maintenance Schedule

	Maintenance Item	Before Work	After Work	Every Week	Every 50 hrs.	Every 100 hrs.	Every 250 hrs.	Every 400 hrs.	Every 500 hrs.	Every 800 hrs.	Every 1000 hrs.	Every 1500 hrs.	Every 3000 hrs.	Every year	Every 2 years	Every 4 years	When Required	Remarks
	Replace hydraulic oil filter					•			Δ									500 hours thereafter
	Check battery fluid level					0								0				Check every 100 hours or every year whichever comes earlier Refer to "Inspection of Battery"
*5	Adjust fan belt tension					0												
*5	Check radiator hoses and clamp bands						0											
*5	Check intake air line (air cleaner hose)						0							0				Check every 250 hours or every year whichever comes earlier
*1	Replace fuel filter cartridge							Δ										
*5	Change engine oil				•			Δ						Δ				Initial 50 hours, thereafter every 400 hours or every year whichever comes earlier
*5	Replace oil filter cartridge				•			Δ						Δ				Initial 50 hours, thereafter every 400 hours or every year whichever comes earlier
*5	Clean water separator								0									
*2.*5	Clean fuel tank interior								0									
*2.*5	Clean water jacket and radiator interior								0									
*2.*5	Replace fan belt								Δ						Δ			Replace every 500 hours or 2 years whichever comes earlier
	Replace hydraulic suction filter								Δ									
*2.*5	Check valve clearance									0								
*2.*3.* 5	Check injector											0						

Maintenance Schedule Page 5-5

	Maintenance Item	Before Work	After Work	Every Week	Every 50 hrs.	Every 100 hrs.	Every 250 hrs.	Every 400 hrs.	Every 500 hrs.	Every 800 hrs.	Every 1000 hrs.	Every 1500 hrs.	Every 3000 hrs.	Every year	Every 2 years	Every 4 years	When Required	Remarks
*2.*3.* 5	Check EGR cooler											0						
*3.*5	Replace oil separator element											Δ						
*2.*3.* 5	Check PCV (Positive Crankcase Ventilation) Valve in the oil separator body											0						
*2.*3.* 5	Check turbocharger												0					
*2.*3.* 4.*5	Replace DPF filters												Δ					
*2.*3.* 5	Check EGR system												0					
	Check electrical wiring condition (Damage, defacement and joint looseness)													0				
*2.*5	Replace air cleaner inner element													Δ				The secondary (inner) element should be removed only if it is to be replaced.
*2.*4.* 5	Check DPF differential pressure pipes and hoses													0				
*2.*5	Check EGR piping													0				
*5	Check exhaust manifold (Crack, gas leakage and mounting screw)													0				
*2.*5	Replace oil separator rubber hose														Δ			
*2.*4.* 5	Replace rubber hose of DPF differential pressure sensor														Δ			
*2.*5	Replace intake hose (After air flow sensor) and inter cooler hose														Δ			
*2.*5	Replace rubber hose of boost pressure sensor														Δ			
*2.*5	Replace EGR cooler hose														Δ			
*2.*5	Replace water hose														Δ			
*2.*5	Replace lubricant hose														Δ			

Page 5-6 Maintenance Schedule

	Maintenance Item	Before Work	After Work	Every Week	Every 50 hrs.	Every 100 hrs.	Every 250 hrs.	Every 400 hrs.	Every 500 hrs.	Every 800 hrs.	Every 1000 hrs.	Every 1500 hrs.	Every 3000 hrs.	Every year	Every 2 years	Every 4 years	When Required	Remarks
*5	Change radiator coolant (L.L.C.)														Δ			
*2.*5	Replace radiator hoses and clamp bands														Δ			
*1.*2.* 5	Replace fuel hoses and clamps														Δ			
*2.*5	Replacement intake air line (air cleaner hose)														Δ			
	Replace hydraulic hoses (Moving part)														Δ			
	Replace hydraulic hoses (Fixed part)															Δ		
	Backlap blades																0	
	Replace brake pads																Δ	
	Replace brake cables																Δ	
	Regrind blades (Reel cutter and Bed knife)																0	Regrind/ Replace blades as and when required
	Replace battery																Δ	

- *1: When biodiesel fuel is used, change the fuel filter cartridge, fuel hose and clamp bands with new ones at intervals half of the usual ones.
- *2: Consult your local Baroness Dealer or local KUBOTA Dealer for this service.
- The items above (*3 marked) are registered as emission related critical parts by KUBOTA in the U.S. EPA nonroad emission regulation.

As the engine owner, you are responsible for the performance of the required maintenance on the engine according to the above instruction.

Please see the engine's warranty statement in detail.

- The items listed above other than *3 marked are not necessary to keep the emission-related warranty valid.
- · *4: Only for D1803-E4, V2403-E4, -TE4
- Failure to perform the maintenance will cause problems that will significantly degrade the engine performance.
- · *5: Refer to the Engine's Owner's Manual.
- · The values for consumables are not guaranteed.
- · Replace the steering cylinder hoses every 2 years.

Maintenance Schedule Page 5-7

Specified Values

Fuel tank capacity		51.0 dm ³ (51.0 L)	Ultra-low sulfur diesel fuel (sulfur-free diesel fuel) or equivalent
Hydraulic tank capacity		44.0 dm ³ (44.0 L)	Shell Tellus S2M46 or equivalent
Quantity of engine oil		9.7 dm ³ (9.7 L)	JASO DH-2 or API Service Grade CJ-4
Coolant volume		12.0 dm ³ (12.0 L)	Including reserve tank (1.0 L)
Front Tire	Type_F	140 kPa (1.4 kg f/cm ²)	31 x 13.50 - 15
Front file	Type_R	140 kPa (1.4 kg f/cm ²)	31 x 13.50 - 15
Rear tire		140 kPa (1.4 kgf/cm ²)	20 × 12.00 - 10
Cutter adjustment spring		40.0 mm (1.575 in)	Length of spring coil

Page 5-8 Maintenance Schedule

DPF

About DPF

▲ Danger

Since it will become extremely hot around the exhaust outlet, do not perform DPF regeneration in a location where fires may occur.

The DPF is a purifying filter that collects PM (soot) from exhaust gas.

When a certain amount of PM (soot) has accumulated, DPF regeneration must be performed automatically or manually in order to restore the filtering function.

Types of DPF Regeneration

DPF regeneration is performed with any of the following four methods.

1. Auto regeneration

Important

This machine can continue to be operated during regeneration.

Raising the exhaust temperature is automatically controlled to perform DPF regeneration.

Regeneration can be performed by this machine.

2. Parked regeneration

Important

This machine cannot continue to be operated during regeneration.

If auto regeneration does not reduce the amount of accumulated PM below the specified value, park this machine in a safe location, and then forcibly perform DPF regeneration.

Regeneration can be performed by this machine.

This machine cannot continue to be operated during regeneration.

3. Manual regeneration

Important

Manual regeneration cannot be performed by the operator.

If manual regeneration is necessary, contact your dealer.

DPF regeneration is performed using a fault diagnostic tool.

Regeneration cannot be performed by this machine.

Perform manual regeneration under any of the following conditions.

- · PM accumulation level 4 is reached.
- · The DPF was replaced.
- The ECU was replaced.
- 4. Replacement of DPF

Important

If replacement of DPF is necessary, contact your dealer.

Replace DPF under any of the following conditions.

- Every 3,000 hrs
- · PM accumulation level 5 is reached.

DPF Page 5-9

Conditions for DPF Regeneration

▲ Danger

Since it will become extremely hot around the exhaust outlet, do not perform DPF regeneration in a location where fires may occur.

Important

If DPF regeneration is canceled before it is completed, the next regeneration request may occur soon since not all of the PM (soot) was removed.

- DPF auto regeneration does not begin unless both of the following two conditions are met
 - The DPF auto regeneration inhibit switch is set to the "Regenerate" position.
 - The coolant temperature is 65 °C or more.
- DPF parked regeneration and manual regeneration do not begin unless all of the following four conditions are met.
 - · The parking brake is applied.
 - The traveling pedal is in the neutral position.
 - The throttle opening is 0% (idling).
 - The coolant temperature is 65 °C or more.
- During DPF regeneration, the operation is canceled if any of the following conditions occur.
 - Any condition for starting regeneration is violated.
 - The ignition key is switched to the "OFF" position.


DPF Regeneration Displays

♠ Danger

Since it will become extremely hot around the exhaust outlet, do not perform DPF regeneration in a location where fires may occur.

The following three icons indicate the DPF regeneration status.

The icon appears at the top of the monitor display.



DPF Regeneration Displays_001

1	Regeneration icon
2	Auto regeneration inhibit icon
3	High exhaust temperature icon

1. Regeneration icon

The regeneration icon appears with DPF regeneration request or during DPF regeneration.

- DPF regeneration request: Blinking
- · During DPF regeneration: Lighting
- Auto regeneration inhibit icon
 The auto regeneration inhibit icon lights up
 when the DPF auto regeneration inhibit
 switch is set to the "Auto regeneration
 inhibit" position.
- 3. High exhaust temperature icon
 The high exhaust temperature icon lights up
 when the exhaust temperature reaches 450
 °C during DPF regeneration.

Page 5-10 DPF

DPF Auto Regeneration

Automatic Regeneration

♠ Danger


Since it will become extremely hot around the exhaust outlet during DPF regeneration, do not perform the operation in a location where fires may occur.

Caution

Normally, set the DPF auto regeneration inhibit switch to the "Auto regeneration"

However, when operating in a location where fires may occur, set the DPF auto regeneration inhibit switch to the "Auto regeneration inhibit" position.

When the DPF auto regeneration inhibit switch is set to the "Auto regeneration" position, perform regeneration as described below, according to the PM accumulation level.



Automatic Regeneration_001

1	DPF auto regeneration inhibit switch
Α	Auto regeneration
В	Auto regeneration inhibit

1. Level 0

Regeneration is not necessary.


2. Level 1

Important

The machine can continue to be operated.

If the conditions for auto regeneration are met, auto regeneration begins and the regeneration icon lights up. However, if regeneration remains

uncompleted even after 30 minutes have passed, the system enters level 2.



Automatic Regeneration_002

1	Regeneration icon
2	Arrow keys

3. Level 2

Important

The machine can continue to be operated. However, during the parked regeneration, the machine cannot be operated.


Auto regeneration continues and the parked regeneration can also be started in

If regeneration remains uncompleted by means of auto regeneration, the regeneration icon begins blinking to request the parked regeneration.

Follow the steps below to perform the parked regeneration.

- [1] Stop machine operations, park in a safe location, and then apply the parking brake.
- [2] Set the throttle opening to 0% (idling).
- [3] Set the DPF parked regeneration switch to the "Engaged" position. Regeneration starts.

DPF Page 5-11



Automatic Regeneration_003

1	DPF parked regeneration switch
Α	Engaged

If the parked regeneration request is ignored and the machine continues to be operated, the system enters level 3.

4. Level 3


Important

The machine cannot continue to be operated.

The auto regeneration cannot be implemented in level 3. Therefore, the parked regeneration must be started immediately.

The following occur in level 3.

- "Excessive PM3" appears in the monitor display. Pressing an arrow key changes the display to "CORRECTIVE ACTION: Start DPF Parked Regeneration immediately".
- · The LED (yellow) lights up.
- The engine output is limited at 50%.



Automatic Regeneration_004

1 LED (yellow)

If the parked regeneration request is ignored and the machine continues to be operated, the system enters level 4.

5. Level 4

Important


Manual regeneration cannot be performed by the operator.

If manual regeneration is necessary, contact your dealer.

The following occur in level 4. Manual regeneration by your dealer must be performed with a fault diagnostic tool.

- "Excessive PM4" appears in the monitor display. Pressing an arrow key changes the display to "CORRECTIVE ACTION: Stop engine!! Contact dealer immediately".
- · The LED (yellow) lights up.
- The engine output is limited at 50%.

Page 5-12 DPF



Automatic Regeneration_005

1 LED (yellow)

If the manual regeneration request is ignored and the machine continues to be operated, the system enters level 5.

6. Level 5


Important

When the system enters level 5, the DPF is completely clogged.

Replacement of DPF is necessary. Contact your dealer.

The following occur in level 5. Replacement of DPF is required.

- "Excessive PM5" appears in the monitor display. Pressing an arrow key changes the display to "CORRECTIVE ACTION: Stop engine!! Contact dealer immediately".
- · The LED (red) lights up.
- The engine output is limited at 50%.



Automatic Regeneration_006

LED (red)

DPF Page 5-13

Auto Regeneration Inhibition




Since it will become extremely hot around the exhaust outlet, do not perform DPF regeneration in a location where fires may occur.



Normally, set the DPF auto regeneration inhibit switch to the "Auto regeneration" position.


However, when operating in a location where fires may occur, set the DPF auto regeneration inhibit switch to the "Auto regeneration inhibit" position.

When the DPF auto regeneration inhibit switch is set to the "Auto regeneration inhibit" position, the auto regeneration inhibit icon appears in the monitor display.



Auto Regeneration Inhibition_001

1	DPF auto regeneration inhibit switch
Α	Auto regeneration
В	Auto regeneration inhibit



Auto Regeneration Inhibition_002

1 Auto regeneration inhibit icon


When the DPF auto regeneration inhibit switch is set to the "Auto regeneration inhibit" position, perform regeneration as described below according to the PM accumulation level.

- 1. Level 0
 Regeneration is not necessary.
- 2. Level 1

Important

The machine can continue to be operated.

The regeneration icon blinks. When the DPF auto regeneration inhibit switch is set to the "Auto regeneration" position, regeneration begins.



Auto Regeneration Inhibition_003

		_
	1	Regeneration icon
	2	Arrow keys

If the regeneration request is ignored and the machine continues to be operated, the system enters level 2.

3. Level 2

Important

The machine cannot be operated during the parked regeneration.


When the system enters level 2, perform the parked regeneration.

Follow the steps below to perform the parked regeneration.

- [1] Stop machine operations, park in a safe location, and then apply the parking brake.
- [2] Set the throttle opening to 0% (idling).
- [3] Set the DPF parked regeneration switch to the "Engaged" position.

 Regeneration starts.

Page 5-14 DPF



Auto Regeneration Inhibition_004

1	DPF parked regeneration switch
Α	Engaged

Levels 3, 4 and 5 are the same as if the DPF auto regeneration inhibit switch is set to the "Auto regeneration" position. Refer to "Automatic Regeneration".

Jacking up the machine

About the Jacking up the machine

▲ Warning

When replacing a tire or beginning any other maintenance or repairs, be sure to chock the wheels to prevent the machine from moving. Before jacking up the machine, park it on a hard, flat surface such as a concrete floor and remove any obstacles that could prevent you from performing the work safely.

When necessary, use an appropriate chain block, hoist, or jack.

Support the machine securely with jack stands or appropriate blocks.


Failure to do so may cause the machine to move or fall, resulting in injury or death.

Use the jack-up points identified in this manual when jacking up the machine.

Only place a jack under the jack-up points specified.

Placing a jack at any other point could result in damage to the frame or other parts.


Jack-up Points



Jack-up Points_001


Jack-up points
Front right frame
Front left frame
Center of pivot
Below rear wheel motors

1. Front right frame




Jack-up Points_002

2. Front left frame




Jack-up Points_003

3. Center of pivot



Jack-up Points_004

Below rear wheel motors There is one jack-up point below each rear wheel motor (left and right).



Jack-up Points_005

Greasing

About Greasing

Since there may be adhesion or damage due to lack of grease on moving parts, they must be greased.

Add urea-based No. 2 grease in accordance with the Maintenance Schedule.

Other locations where the specified grease or lubricant is used are indicated in "Greasing Points".


Add grease using the specified grease or lubricant.

Greasing Points

Type_F

Grease nipples are installed in the following locations.

Add grease every 50 hours of operation.



Type_F_001

1390_1_001		
		No. of
	Location	greasing
		points
1	Mower arm fulcrum	5
2	Lift arm fulcrum	5
3	Brake lever shaft	2
4	Traveling pedal shaft fulcrum	2
5	Pivot	3
6	Neutral position area	2
7	Reel housing	5
8	Rear roller	10
9	Front roller	10
10	Mower unit fulcrum	5


Page 5-16 Greasing

1. Mower arm fulcrum


There is one greasing point on each mower arm fulcrum connected to a mower unit. Grease mower units #2 and #3 in the swiveled position.

"Swiveling Mower Units #2 and #3" (Page 5-24)

Mower units #1, #4 and #5



Type_F_002 Mower units #2 and #3




Type_F_003

2. Lift arm fulcrum


There is one greasing point on each lift arm fulcrum connected to a mower unit. Lower the mower units before greasing the lift arm fulcrums.

Mower units #1 and #4




Type_F_004

Mower units #2 and #3



Type_F_005


Mower unit #5



Type_F_006

3. Brake lever shaft


There are two greasing points on the brake lever shaft.



Type_F_007

Greasing Page 5-17


4. Traveling pedal shaft fulcrum
There are two greasing points on the traveling pedal shaft fulcrum.



Type_F_008


5. Pivot

Middle between the rear wheels




Type_F_009

Rear left wheel




Type_F_010

Rear right wheel



Type_F_011


Neutral position area There are two greasing points on the neutral position area.



Type_F_012

7. Reel housing

There is one greasing point on each mower unit reel housing.




Type_F_013

Page 5-18 Greasing

8. Rear roller


There is one greasing point on the left and right of the rear roller of each mower unit.



Type_F_014

9. Front roller


There is one greasing point on the left and right of the front roller of each mower unit.



Type_F_015

10. Mower unit fulcrum

There is one greasing point on each mower unit fulcrum.




Type_F_016

Type_R

Grease nipples are installed in the following locations.

Add grease every 50 hours of operation.



Type R 001

	1,700_1(_001	
		No. of
	Location	greasing
		points
1	Mower arm fulcrum	5
2	Lift arm fulcrum	5
3	Brake lever shaft	2
4	Traveling pedal shaft fulcrum	2
5	Pivot	3
6	Neutral position area	2
7	Reel housing	5
8	Rear roller	10


Greasing Page 5-19

1. Mower arm fulcrum

There is one greasing point on each mower arm fulcrum connected to a mower unit. Grease mower units #2 and #3 in the swiveled position.


"Swiveling Mower Units #2 and #3" (Page 5-24)

Mower units #1, #4 and #5



Type_R_002

Mower units #2 and #3




Type_R_003

2. Lift arm fulcrum


There is one greasing point on each lift arm fulcrum connected to a mower unit. Lower the mower units before greasing the lift arm fulcrums.

Mower units #1 and #4




Type_R_004

Mower units #2 and #3



Type_R_005


Mower unit #5



Type_R_006

3. Brake lever shaft


There are two greasing points on the brake lever shaft.



Type_R_007

Page 5-20 Greasing


4. Traveling pedal shaft fulcrum
There are two greasing points on the traveling pedal shaft fulcrum.



Type_R_008


5. Pivot

Middle between the rear wheels




Type_R_009

Rear left wheel




Type_R_010

Rear right wheel



Type_R_011


Neutral position area There are two greasing points on the neutral position area.



Type_R_012

7. Reel housing

There is one greasing point on each mower unit reel housing.




Type_R_013

Greasing Page 5-21

8. Rear roller

There is one greasing point on the left and right of the rear roller of each mower unit.



Type R 014

Maintenance (Mower)

Back Lapping of Reel Cutter (Cutting Cylinder)

Back lapping is work similar to sharpening a cooking knife. If the edges of the reel cutter (cutting cylinder) and the bed knife (bottom blade) become blunt and make cutting difficult, both the reel cutter (cutting cylinder) and the bed knife (bottom blade) should be simultaneously sharpened by reversing the reel cutter (cutting cylinder) with an abrasive paste applied.

However, back lapping is a temporary measure and would not restore the sharpness completely.

If the edges of the reel cutter (cutting cylinder) and the bed knife (bottom blade) become blunt and make cutting difficult, follow the steps below to perform back lapping.



Both the reel cutter (cutting cylinder) and the bed knife (bottom blade) are edged tools. Handle them carefully, since they could cut your hands and feet.

▲ Caution

Be careful not to inhale exhaust gas during back lapping.

▲ Caution


During back lapping, the reel cutter (cutting cylinder) rotates.

Keep hands and feet away from moving parts.

▲ Caution

Do not perform back lapping with any other persons.

1. Have the following items ready: Strips of newspaper, Abrasive [Back lapping powder mixed with oil; or gel compound (Baroness genuine abrasive)], Brush.



Back Lapping of Reel Cutter (Cutting Cylinder)_001

1	Newspaper
2	Back lapping powder
3	Gel compound
4	Brush

Note:

The mixing ratio for the abrasive, in volume, is one part back lapping powder (#150 - #200) to three or four parts oil.




When handling the reel cutter (cutting cylinder) and the bed knife (bottom blade), wear gloves to protect your hands. Pay attention not to let the reel cutter (cutting cylinder) catch your gloves. Otherwise, you may injure your hand or fingers.

Important

Check the sharpness of the blade by checking the blade engagement after cutting grass.

2. Stop the engine.

3. Set the reel rotation/stop switching lever to the "Stop" position.



Back Lapping of Reel Cutter (Cutting Cylinder)_002


1	Reel rotation/stop switching lever
Α	Rotate
В	Stop

- 4. Insert two or three strips of newspaper into the space between the reel cutter (cutting cylinder) and the bed knife (bottom blade) at an angle of 90 degrees. Then, rotate the reel cutter (cutting cylinder) counter-clockwise (when you face the mower unit from the left) by hand to check the sharpness of the blades.
- 5. Check the sharpness of the entire range (three or four points from the left edge to the right one) of the reel cutter (cutting cylinder).
- 6. Using a piece of chalk, mark locations on the blade that are sharp.
- 7. Shift the reel rotation/stop switching levers of the hydraulic motors in the mower units to be used for back lapping to the "Rotate" position.
 - Shift the levers for the mower units for which you will not perform back lapping to the "Stop" position.
- 8. Sit on the seat, apply the parking brake, and then start the engine. Note:

If the reel rotation switch is set to the "ON" position, the engine will not start.

9. Lower all mower units to the ground.


10. Open the hood, and then set the reel reverse switch to the "ON" position (reverse rotation).



Back Lapping of Reel Cutter (Cutting Cylinder)_003

1	Reel reverse switch
Α	ON (reverse)
В	OFF (normal rotation)

- 11. Run the engine at a low rpm.
- 12. Set the reel rotation switch to the "ON" position to rotate the reel cutters (cutting cylinders) for back lapping.



Back Lapping of Reel Cutter (Cutting Cylinder) 004

1	Reel rotation switch
Α	ON
В	OFF

- 13. With the reel rotation/stop switching lever, adjust the rotation speed of the reel cutter (cutting cylinder).
- 14. Apply the abrasive evenly with the brush on the top side of reel cutter (cutting cylinder) where the newspaper was cut well or of chalk-marked locations. (Never apply to blunt areas.)
- 15. Idle the engine for a while, and when contact noise is no longer heard, set the reel rotation switch to the "OFF" position to stop the reel cutters (cutting cylinders).
- 16. Stop the engine.

- 17. Wash off or wipe off with a cloth, etc., the abrasive from the reel cutter (cutting cylinder), and then check it for sharpness.
- 18. Repeat steps 4 to 17 until the entire range (three or four points from the left edge to the right one) of the reel cutter (cutting cylinder) is uniformly sharpened.
- 19. Finally, apply abrasive to the entire blade width of the reel cutter (cutting cylinder) and perform final back lapping.
- 20. Set the reel rotation switch to the "OFF" position to stop the rotation of the reel cutters (cutting cylinders), stop the engine, and then carefully and thoroughly wash off any remaining abrasive.
- 21. Set the reel reverse switch to the "OFF" position (normal rotation).
- 22. Shift the reel rotation/stop switching lever to the "Stop" position.
- 23. While checking the blade for sharpness, adjust blade engagement.

Maintenance (Main Body)

Swiveling Mower Units #2 and #3



Both the reel cutter (cutting cylinder) and the bed knife (bottom blade) are edged tools. Handle them carefully, since they could cut your hands and feet.




Be careful not to inhale exhaust gas while swiveling the mower units.

Maintenance can be performed more easily with mower units #2 and #3 swiveled.

1. Lower the mower units, and then stop the engine.


2. Remove the clip pin, and then remove the grip pin.



Swiveling Mower Units #2 and #3_001


1	Clip pin
2	Grip pin

3. Swivel the mower unit toward the outside of the machine.



Swiveling Mower Units #2 and #3_002


4. Fully insert the grip pin into the locking hole for maintenance, and then install the clip pin in the grip pin.



Swiveling Mower Units #2 and #3_003

1	Grip pin
2	Clip pin

5. Start the engine, and then raise the mower units.



Swiveling Mower Units #2 and #3_004


6. After the maintenance is completed, reverse the procedure to return the machine to its original condition.

Removing/Installing Tires

Front Tires

Follow the steps below to remove the front tires:

1. Loosen the bolts.



Front Tires 001

11011111100_001		
1	Front tire	
2	Heat-treated bolt	

- 2. Securely place the jack beneath the jack-up point of the front left/right frame area, and then raise it until the tire lifts off the ground. "Jack-up Points" (Page 5-15)
- 3. Remove the bolts.
- 4. Remove the tire from the wheel mounting seat.



Refer to the Tightening Torque table. Note that the Baroness product warranty may not apply to defects caused by incorrect or overtorque tightening etc.

Important


Tighten the bolts in the tightening order (crosswise).

For installing the front tires, reverse the removing procedure.

Rear Tire

Follow the steps below to remove the rear tire.

Loosen the bolts.



Rear Tire_001

1	Rear tire
2	Heat-treated bolt

- 2. Securely place the jack beneath the jack-up point below the rear wheel motor, and then raise it until the tire lifts off the ground.

 "Jack-up Points" (Page 5-15)
- 3. Remove the bolts.
- 4. Remove the tire from the wheel mounting base.



Refer to the Tightening Torque table. Note that the Baroness product warranty may not apply to defects caused by incorrect or overtorque tightening, etc.

Important

Tighten the bolts in the tightening order (diagonally).

For installing the rear tire, reverse the removing procedure.

Adjustment of Belt Tension



A Caution

Be sure to stop the engine before adjusting the belts.

Important

Make sure that the belt has the specified amount of tension.

If the belt becomes slack due to frequent use, it may jump or slip.

In addition, if it is overtightened, it may wear prematurely.

If necessary, adjust it, and always check the belt for appropriate tension.


Fan Belt



Be sure to stop the engine before adjusting the belts.

For details on handling the engine, please refer to the Engine's Owner's Manual.

- 1. Press the middle of the belt with your finger to check the belt tension.
- 2. If the belt is too slack, loosen bolts A and B (that affix the alternator), and then move the alternator to adjust the tension.



Fan Belt_001

1	Fan belt
2	Blade
3	Alternator
4	Bolt A
5	Bolt B

Adjustment of Brake

♠ Danger

Make sure that the brake wire is not cracked or damaged.


Important

If the brake is not sufficiently effective due to a wider clearance gap between the brake disc and the brake lining, adjust the clearance. The wire is used for fine adjustments.

Important

Adjust the brake with the brake lining.

The brake lining wear limit is 3.0 mm (0.12 in).




Adjustment of Brake_001

1	Brake disc
2	Brake lining

Caution

Make sure that the lever is maintained in the open position (neutral).


1. For each wheel, fully tighten the adjustment bolt on the brake disc side.



Adjustment of Brake_002

1	Adjustment bolt (on brake disc side)		
2	Lever		
А	Open (neutral)		

 Reduce the clearance by loosening the lock nut, then tightening the adjustment nut.
 Tighten the adjustment nut until the brake lining contacts the friction surface of the disc.



Adjustment of Brake_003


1 Brake disc	
2	Wire
3	Lock nut
4	Adjustment nut

♠ Danger

Too narrow clearance gap between the brake disc and brake lining may cause heat generation and fire.

- 3. Loosen the adjustment nut to adjust the clearance gap between the brake disc and brake lining to about 0.2 mm (0.0079 in).
- 4. Securely place the jack beneath the jack-up point of the front left/right frame area, and then raise it until both tires lift off the ground.
- 5. Check that the disc rotates freely.
- 6. Fully tighten the lock nut while holding the adjustment nut in place.

7. With the brake pedal released, obtain a play of 1.0 mm (0.039 in) at the joint part of the inner wire.



Adjustment of Brake 004


Inner wireAdjustment bolt	
4 Joint part	

- 8. Use a wrench to loosen the lock nut and tighten it after making the adjustment with the adjustment bolt.
- 9. Drive, and then check the following.
 - Make sure that heat is not generated in the brake area.
 - Make sure that the left and right brakes are equally effective.

▲ Danger

It would be extremely dangerous and may result in an unexpected accident if the left and right brakes are not equally effective.

10. If the left and right brakes are not equally effective, make fine adjustments with the adjustment bolt on the brake disc side.



Adjustment of Brake_005

1 Adjustment bolt (on brake disc side)

Break-in of Brakes

If the brake shoes or brake pads are worn, replace them with new ones.

Immediately after replacement, drive to break in the brakes if the effectiveness of the brakes is low.

While driving, lightly operate the brakes to break in the contact areas.

Adjusting the Neutral Position of the Piston Pump



Make sure not to touch rotating tires.




When adjusting the neutral position, pay close attention to abrupt start of the machine. Place the jacks beneath the jack-up points, and then lift the machine until all the tires get off the ground.

If the machine moves forward or backward while the traveling pedals are released, they are not set to the neutral position.

Follow the steps below to make adjustments.


- 1. Stop the engine.
- 2. Place the jacks beneath the jack-up points, and then lift the machine off the ground.
- 3. Make sure that no tires come into contact with the jack stand.
- 4. Make sure that the steering wheel is raised completely.
- 5. Pull up the forward/backward adjustment lever, and then slide the seat backward completely.



Adjusting the Neutral Position of the Piston Pump_001

1	Forward/backward adjustment lever	
2	Seat	


6. While pulling up the lever, tilt the seat upward.



Adjusting the Neutral Position of the Piston Pump_002

1	Lever
2	Seat

- 7. Start the engine, and rev it up to the maximum rpm.
- 8. Set the 2WD/4WD selector switch to the "2WD" position.
- 9. Adjust the neutral position.
 - [1] If the front tires rotate forward, loosen the lock nuts, and then turn the neutral adjustment rod to shorten it.
 - [2] If the front tires rotate in reverse, loosen the lock nuts, and then turn the neutral adjustment rod to extend it.



Adjusting the Neutral Position of the Piston Pump_003

1	Lock nut A (Left-hand thread)
2	Neutral adjustment rod
3	Lock nut B (Right-hand thread)

10. Find the position where the front wheels stop, and then tighten the lock nuts.

Change of Fuse

Fuse Box




Before performing maintenance on the electrical system, be sure to disconnect the negative terminal of the battery.



If a fuse blows, a short may have occurred within the electrical circuit.

Check for the cause, such as faulty terminal connections, damaged wiring or terminals, or incorrect wiring.

The fuse box includes spare fuses and tools.




Fuse Box_001

1 Fuse box

The machine uses a mini fuse for automobiles.

Replace an old fuse with a new fuse of the specified capacity.




Fuse Box_002

Α	5 A	ECU_KeySwitch_ON
В	5 A	Alternator
С	5 A	Display
D	15 A	Relay box 1(differential lock switch, #3 proximity switch, reel rotational direction switch)
E	15 A	Relay box 2 (2WD/4WD selector switch, #4/#5 proximity switches)
F	-	-
G	5 A	ECU_KeySwitch_Start
Н	5 A	ECU_Parked Regeneration Switch/Auto
11	15 A	Regeneration Inhibit Switch
I	5 A	Operating oil buzzer
J	5 A	Water temperature buzzer
K	5 A	
L	5 A	Spara
М	15 A	Spare
N	15 A	
0	Fuse	removal tool

Fusible Link

Fuse capacities of the fusible links are 30 A and 50 A.



Fusible Link_001

	1	Fusible link (50 A)
ľ	2	Fusible link (30 A)

Long-Term Storage

Before Long-Term Storage

- Remove dirt, grass clippings, debris, oil stains etc. completely.
- Supply oil and apply grease to appropriate parts.
- · Remove the negative terminal of the battery.

Long-Term Storage Page 5-29

Page 5-30 Long-Term Storage

BARONESS

EU Declaration of Conformity

Product Identification

Product: Make: Type: Version(s):

BARONESS LM3210 Not Applicable

Starting Serial No. : Measured Sound Power Level:

Guaranteed Sound Power Level:

99.86 LWA LWA 103 dB

Manufacturer Name: Address: Kyoeisha Co., Ltd. 1-26 Miyuki-cho, Toyokawa, Aichi-pref.,Japan

Conforms to the following Directives

2006/42/EC 2014/30/EU

Machinery (MD)

Electromagnetic compatability (EMC) 2000/14/EC Noise emissions from outdoor equipment
We has been designed and manufactured using the following specifications

ISO 12100 : 2010 (2006/42/EC) ISO 5395-1: 2013 (2006/42/EC) ISO 5395-3: 2013 (2006/42/EC) ISO 14982 : 1998 (2014/30/EU)

Technical Documentation Keeper's Name:

Kyoeisha Co., Ltd.

Keeper's Address :

1-26 Miyuki-cho, Toyokawa, Aichi-pref., Japan

Compiler of the technical file (2006/42/EC)

Kyoeisha U.K.Ltd.

Address:

Unit 5 Hatch Industrial Park Grewell Road, Basingstke Hampshire RG24 7NG, the United Kingdom

Conformity assessment procedures

Internal production control: Module A (2006/42/EC) EC-type examination : Module B (2014/30/EU)

Internal control of production with assessment of technical documentation and periodical checking (2000/14/EC)

Involved Notified Body (2000/14/EC)

Name:

Address : Certificate / Report No.: 11, Route de Sandweiler 5230 Sandweiler Luxembourg SNCH*2000/14*2005/88*2911*00/TCLM3210-00

Place: Japan

Date: 6 July 2016 (06 / 07 / 2016)

Signature:

muga kaneko Name : Position: Quality Dept. Manager

Déclaration de conformité UE

Identification du produit

Produit: Fabriquant: Type: Version(s):

Tondeuse à gazon BARONESS LM3210 Non applicable

Numéro de série de début :

10015

Niveau de puissance acoustique mesuré : Niveau de puissance acoustique garanti :

LwA 99.86 LWA 103 dB Kyoeisha Co. Ltd.

Fabricant Nom:

1-26, Miyuki-cho, Toyokawa, préfecture d'Aichi, Japon

Adresse: Conforme aux directives suivantes :

2006/42/CE Machine (MD)

2014/30/UE 2000/14/CE

Compatibilité électromagnétique (CEM) Émissions sonores de l'équipement de plein air Conception et fabrication en respect des spécifications suivantes :

ISO 12100 : 2010 (2006/42/CE) ISO 5395-1: 2013 (2006/42/CE) ISO 5395-3: 2013 (2006/42/CE) ISO 14982 : 1998 (2014/30/UE)

Fiche technique

Margue: Adresse de la marque : Kyoeisha Co., Ltd.

1-26, Miyuki-cho, Toyokawa, préfecture d'Aichi, Japon

Compilateur de la fiche technique (2006/42/CE) Nom:

Kvoeisha U.K. Ltd.

Unit 5 Hatch Industrial Park Greywell Road, Basingstoke Hampshire RG24 7NG, Royaume-Uni

Adresse: Procédures d'évaluation de la conformité

Contrôle de production interne : module A (2006/42/CE)

Examen de type CE: module B (2014/30/UE)

Contrôle interne de la production avec évaluation de la fiche technique et vérification périodique (2000/14/CE)

Organisme notifié impliqué (2000/14/CE)

Nom: Adresse: SNCH

Nº de certificat/rapport :

11. Route de Sandweiler 5230 Sandweiler, Luxembourg SNCH*2000/14*2005/88*2911*00/TCLM3210-00

EU00 - 1

Declaración de conformidad de la UE

Identificación del producto

Producto: Cortacésped Marca: BARONESS Tipo: LM3210 Versión: No aplicable N.º de serie inicial: 10015

Nivel de potencia sonora medido: LWA 99.86 dB Nivel de potencia sonora garantizado: LWA 103

Fabricante Kyoeisha Co., Ltd. Nombre: Dirección: 1-26 Miyuki-cho, Toyokawa, Aichi-pref., Japón

Cumple las siguientes Directivas

2006/42/CE Maquinaria (MD) 2014/30/UE Compatibilidad electromagnética (EMC)

2000/14/CE Emisiones sonoras de máquinas de uso al aire libre

Se ha diseñado y fabricado utilizando las siguientes especificaciones

ISO 12100 : 2010 (2006/42/CE) ISO 5395-1 : 2013 (2006/42/CE) ISO 5395-3 : 2013 (2006/42/CE) ISO 14982 : 1998 (2014/30/UE)

Documentación técnica Nombre del responsable:

Kyoeisha Co., Ltd. Dirección del responsable:

1-26 Miyuki-cho, Toyokawa, Aichi-pref., Japón

Compilador del archivo técnico (2006/42/CE)

Nombre: Kyoeisha U.K. Ltd. Dirección:

Procedimientos de evaluación de conformidad

Unit 5 Hatch Industrial Park Greywell Road, Basingstoke Hampshire RG24 7NG, Reino Unido

Control de fabricación interno: Módulo A (2006/42/CE)

Examen de tipo CE: Módulo B (2014/30/UE)

Control interno de fabricación con evaluación de documentación técnica y comprobaciones periódicas (2000/14/CE)

Organismo notificado implicado (2000/14/CE)

Nombre:

Dirección: 11, Route de Sandweiler 5230 Sandweiler Luxemburgo Certificado/Informe n.º: SNCH*2000/14*2005/88*2911*00/TCLM3210-00

(de)

EU-Konformitätserklärung

Produktbeschreibung

Produkt: Rasenmäher BARONESS Modell: LM3210 Version(en): Nicht zutreffend Startseriennummer: 10015

Gemessener Schallleistungspegel: LWA 99.86 dB Garantierter Schallleistungspegel: LWA 103 dB Hersteller Kvoeisha Co., Ltd. Name:

Adresse: Entspricht den folgenden Richtlinien

2006/42/EG Maschinenrichtlinie 2014/30/EU

Elektromagnetische Verträglichkeit (EMV) 2000/14/EG Geräuschemission von im Freien betriebenen Geräten

Unter Anwendung der folgenden Bestimmungen entwickelt und hergestellt

ISO 12100 : 2010 (2006/42/EG) ISO 5395-1: 2013 (2006/42/EG) ISO 5395-3: 2013 (2006/42/EG) ISO 14982 :1998 2014/30/EU) Technische Dokumentation

Name des Halters Kyoeisha Co., Ltd.

Adresse des Halters 1-26 Miyuki-cho, Toyokawa, Aichi-pref., Japan

Technische Unterlagen erstellt von (2006/42/EG)

Name: Kvoeisha U.K.Ltd. Adresse:

Unit 5 Hatch Industrial Park Grewell Road, Basingstoke Hampshire RG24 7NG, Großbritannien Konformitätsbewertungsverfahren

1-26 Miyuki-cho, Toyokawa, Aichi-pref., Japan

Interne Produktionskontrolle: Modul A (2006/42/EG) EG-Baumusterprüfung: Modul B (2014/30/EU)

Interne Produktionskontrolle mit Bewertung der technischen Unterlagen und regelmäßiger Überprüfung (2000/14/EG)

Beteiligte benannte Stelle (2000/14/EG)

Name:

Adresse: 11, Route de Sandweiler 5230 Sandweiler Luxemburg Bescheinigung/Bericht Nr.: SNCH*2000/14*2005/88*2911*00/TCLM3210-00

EU-försäkran om överensstämmelse

Produktidentifikation

Version(er):

Produkt: Märke: Typ:

Gräsklippare BARONESS LM3210 Ei aktuellt 10015

LWA

Serienummer startar på: Uppmätt ljudeffektnivå: Garanterad ljudeffektnivå:

99.86 dB Kyoeisha Co., Ltd.

Tillverkare Namn:

Adress:

1-26 Miyuki-cho, Toyokawa, Aichi-pref., Japan

Uppfyller följande direktiv 2006/42/EG

Maskindirektivet

2014/30/EU 2000/14/EG

Elektromagnetisk kompabilitet (EMC)
Bulleremission från utomhusutrustning Följande kravspecifikationer har följts vid konstruktion och tillverkning

ISO 12100 : 2010 (2006/42/EG) ISO 5395-1: 2013 (2006/42/EG) ISO 5395-3 : 2013 (2006/42/EG) ISO 14982 : 1998 (2014/30/EU) Teknisk dokumentation

Innehavarens namn: Innehavarens adress: Kyoeisha Co., Ltd.

1-26 Miyuki-cho, Toyokawa, Aichi-pref., Japan

Den tekniska filen(2006/42/EG) har tagits fram av

Namn:

Adress:

Förfarande för bedömning av överensstämmelse Intern produktionskontroll: Modul A (2006/42/EG) EG-typprovning: Modul B (2014/30/EU)

Intern kontroll av produktion med fastställande av teknisk dokumentation och periodiska kontroller (2000/14/EG)

Anmält organ (2000/14/EG)

Namn:

Adress: Certifikatnummer/rapportnummer:

11, Route de Sandweiler 5230 Sandweiler Luxembourg SNCH*2000/14*2005/88*2911*00/TCLM3210-00

Unit 5 Hatch Industrial Park Grewell Road, Basingstoke Hampshire RG24 7NG, Storbritannien



